



Mandis AXD7698 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis AXD7698 Remote Control Instructions 

Contents

- [1 Mandis AXD7698 Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Overview](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)



Mandis AXD7698 Remote Control



Product Information

Specifications

- **Model:** Pioneer AXD7698
- **Compatibility:** Replacement remote control for Pioneer devices

Product Usage Instructions

• Power and Volume Control

To turn on the device, press the **Power** button. To adjust the volume, use the **Volume+** and **Volume-** buttons.

• Input Selection

To switch between different input sources, use the **Input Select** button followed by the corresponding number or name of the input source.

Playback Controls

For playback controls, use the following buttons:

- **Play/Pause:** Press the **Play** button to start playback. Press it again to pause.
- **Stop:** Press the **Stop** button to stop playback.
- **Fast Forward/Rewind:** Use the **>>** and **<<** buttons to fast forward or rewind during playback.
- **Previous/Next Track:** Press the **<>** buttons to go to the previous or next track.

Menu Navigation and Settings

To navigate through menus and access settings, use the following buttons:

- **Home/Menu:** Press the **Home** or **Menu** button to access the main menu.
- **OK/Enter:** Use the **OK** or **Enter** button to confirm selections or enter submenus.
- **Back/Return:** Press the **Back** or **Return** button to go back to the previous menu or screen.

Additional Features


The remote control offers various additional features:

- **Mute/Dimmer:** Press the **Mute** button to mute the audio or adjust the display brightness using the **Dimmer** button.
- **Sleep/Timer:** Use the **Sleep** button to set a sleep timer for the device.
- **Favorites/Markers:** Press the **Fav/Marker/PC** button to access favorite channels or mark positions during playback.
- **Audio/Language:** Use the **Audio/Lang I/II** button to change audio tracks or language settings.
- **Repeat:** Press the **Repeat** button to repeat a section or a whole track during playback.

Frequently Asked Questions (FAQ)

- **Q: Where can I find a replacement remote control for Pioneer AXD7698?**
 A: You can find a replacement remote control for Pioneer AXD7698 at the following website: [Replacement Remote Control for Pioneer AXD7698](#)

Overview

Original		Replacement		Original		Replacement	
	Standby / On		Power		Volume-		Vol-
	BD		Shift + 5		Mute		Mute / Dimmer
	DVD		Shift + 2		Audio		Audio / Lang I/II
	DVR / BDR		Shift + 7		Up		Up
	HDMI		Shift + 0		Video		Picture / Format
	TV		Shift + 1		Tools Menu		Setup / OPT /
	CD		Shift + 3		Left		Left
	NET		Shift + 9		Enter		OK
	ADPT		Shift + Guide / EPG / -/-		Right		Right



	iPod / USB		Shift + 8
	SAT / CBL		Shift + Fav / Marker / PC
	MHL		Shift + 4
	TUNER		Shift + 6
	Input Select ↶		CH- / Page-
	Input Select ↷		CH+ / Page+
	i / Status		Info / Angle
	Volume+		Vol+

	Home Menu		Menu / Home
	iPod Ctrl.		D.Menu / Top
	Down		Down
	Return		Back / Return
	Features PHASE		Red / Netflix / Search
	Features ECO		Yellow / YouTube / Repeat
	MPX		Shift + Pause / Step /
	Pause		Pause / Step / Freeze



Original	Replacement
	Shift + Play /
	Play / Slow
	Shift + Stop /
	Stop / Hold
	Shift + I<< / Preset-
	I<< / Preset-
	Shift + >>I / Preset+
	>>I / Preset+
	Shift + << /
	<< / Tune-
	Shift + >> /
	>> / Tune+
	Subtitle / EQ
	1
	Smart / List
	2
	Eject / Surround

Original	Replacement
	3
	Fav / Marker / PC
	Sound / Title
	4
	TV/Radio /
	Zoom / Size
	5
	6
	Text / Goto
	Display / Media
	7
	Shift + Audio / Lang I/II
	Shift + Mute / Dimmer
	8
	9
	Sleep / Timer
	Green / APP / Repeat

	Mandis AXD7698 Remote Control [pdf] Instructions AXD7698 Remote Control, AXD7698, Remote Control, Control
	Mandis AXD7698 Remote Control [pdf] Instructions AXD7698 Remote Control, AXD7698, Remote Control, Control
	Mandis AXD7698 Remote Control [pdf] Instructions AXD7698 Remote control, AXD7698, Remote control, control
	Mandis AXD7698 Remote Control [pdf] Instructions AXD7698 Remote Control, AXD7698, Remote Control, Control

References

- [M Replacement remote control for PIONEER AXD7698](#)
- [User Manual](#)