



Mandis AXD7737 Replacement Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis AXD7737 Replacement Remote Control Instructions 

Mandis AXD7737 Replacement c Instructions








Contents






- 1 Remote Control
- 2 Documents / Resources
 - 2.1 References
- 3 Related Posts


Remote Control



Original	Recharge
 Standby/on	 Power
 Open/Close	 Eject / Surround
 Disc/Bluetooth	 9

 FM	 6
 Preset/Album	 CH+ / Page+
 USB/Audio In	 8
 <</l<<	 Color Wheel << / Tune
 Play	 Play / Slow
 Pause	 Pause / Step / Freeze
 >>/>>l	 >> / Tune+

 Preset/Album	 CH- / Page
 Repeat	 Green / APP / Repeat
 Vol+	 Vol+
 Stop	 Stop / Hold
 Vol-	 Vol-
 Shuffle	 Blue / Prime Video / Random
 Mute	 Mute / Dimmer
 Dimmer/Display	 Display / Media
 Program	 TV/Radio /
 EQ	S  ubtitle / EQ

 Clock	 Shift + Sleep / Timer
 Sleep/Timer	 Sleep / Timer



<https://tout-telecommandes.fr/fr/Pioneer/1058392-65904-telecommande-de-remplacement-pour-Pioneer-AXD7737-8.50.1.RCXEM222RR2.html>



Documents / Resources

	Mandis AXD7737 Replacement Remote Control [pdf] Instructions AXD7737 Replacement Remote Control, AXD7737, Replacement Remote Control, Remote Control, Control
---	---

References

-  [Télécommande qui remplace PIONEER AXD7737 \(8.50.1.RCXEM222RR2\)](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.