



Mandis DPV-5300X Targa Remote Control Instruction Manual

[Home](#) » [Mandis](#) » Mandis DPV-5300X Targa Remote Control Instruction Manual 

Contents

- [1 Mandis DPV-5300X Targa Remote Control](#)
- [2 Product Information](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 OVERVIEW](#)
- [6 Replacement Parts](#)
- [7 BUTTON DESCRIPTIONS](#)
- [8 Documents / Resources](#)
 - [8.1 References](#)
- [9 Related Posts](#)



Mandis DPV-5300X Targa Remote Control



Product Information

The Targa DPV5300X is a versatile DVD-VCR combo that allows you to enjoy your favorite movies and record your favorite TV shows. It features a user-friendly remote control with various functions for easy operation.

Specifications

- Model: Targa DPV5300X
- Type: DVD-VCR Combo
- Power: AC 120V, 60Hz
- Dimensions: [Insert dimensions]
- Weight: [Insert weight]

Product Usage Instructions

DVD Functions

Use the remote control to navigate through the DVD menu and control playback:

- **Power:** Press to turn the DVD player on or off.
- **Open/Close:** Press to open or close the disc tray.
- **Up/PR/TRK+:** Press to move up or track forward in a menu or during playback.
- **Left/Right:** Press to navigate left or right in a menu.
- **OK/Enter:** Press to confirm a selection.
- **Down/PR/TRK-:** Press to move down or track backward in a menu or during playback.
- **Setup:** Press to access the setup menu.
- **Return:** Press to go back to the previous menu.
- **Pause/Step II:** Press to pause playback or step through frames.
- **Skip:** Press to skip to the next track or chapter.
- **Stop:** Press to stop playback.
- **> Forward:** Press to fast forward during playback.
- **Program:** Press to program a sequence of tracks or chapters.
- **Clear:** Press to clear a programmed sequence or input.

VCR Functions

Use the remote control to control VCR functions:

- **Power:** Press to turn the VCR on or off.
- **Eject:** Press to eject a tape.
- **TV/VCR:** Press to switch between TV and VCR modes.
- **AV:** Press to switch the input source to AV mode.
- **Up/PR/TRK+:** Press to move up or track forward in a menu or during playback.
- **Down/PR/TRK-:** Press to move down or track backward in a menu or during playback.
- **Right/Left:** Press to navigate right or left in a menu.
- **OK:** Press to confirm a selection. **i:** Press to display information about the current program.
- **Pause/Step:** Press to pause playback or step through frames.
- **Stop:** Press to stop playback.
- **Forward/Clear:** Press to fast forward or clear a programmed sequence.

FAQ (Frequently Asked Questions)

- Where can I purchase a replacement remote control for Targa DPV5300X?
- You can purchase a replacement remote control for Targa DPV5300X from the following website: [Replacement Remote Control for Targa DPV5300X](#)

Targa DPV5300X-DVD

OVERVIEW



Replacement Parts

Original	Replacement
 Power	 Power
 Open / Close	 Eject
 DVD	 Smart
 VCR	 Media
 Display	 Info
 Disc Menu	 D. Menu
 Up / PR/TRK+	 Up
 Up / PR/TRK+	 Ch +
 Left	 Left
 OK / Enter	 Ok
 Right	 Right
 Down / PR/TRK-	 Down
 Down / PR/TRK-	 Ch -
 Setup	 Menu
 Return	 Back
 Pause / Step	 Pause
 I<< Skip	 I<<

	>>I Skip		>>I
	Stop		Stop
	<< Backward		<<
	Play		Play
	>> Forward		>>
	Program		Sleep
	Clear		Exit
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Audio		Dual
	Subtitle		Subt
	Zoom	 + 	Shift + Eject
	Angle		Format
	Marker		Pre Ch
	Search		TV/R
	Title		Vol +
	Repeat		Text
	Random		3D
	A-B	 + 	Shift + Text

BUTTON DESCRIPTIONS



Targa DPV5300X-VCR

OVERVIEW



Replacement Parts

Original

Replacement

	Power		Power
	Eject		Eject
	TV / VCR		Menu
	DVD		Smart
	VCR		Media
	AV		AV
	CLK / CNT		3D
	Up / PR/TRK+		Up
	Up / PR/TRK+		Ch +
	Down / PR/TRK-		Down
	Down / PR/TRK-		Ch -
	Right		Right
	Left		Left
	OK		Ok
	i		Info
	Pause / Step		Pause
	Stop		Stop

	<< Backward		<<
	Play		Play
	>> Forward		>>
	Clear		Exit
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Audio		Dual
	Search		TV/R
	CM Skip		Yellow
	Rec / ITR		Rec
	LP		Sleep
	Show View		Options

BUTTON DESCRIPTIONS



<https://all-remote-controls.co.uk/en/Targa/1060822-92996-replacement-remote-control-for-Targa-DPV-5300X.html>

Documents / Resources



[Mandis DPV-5300X Targa Remote Control](#) [pdf] Instruction Manual
DPV-5300X Targa Remote Control, DPV-5300X, Targa Remote Control, Remote Control, Control

References

- [M Replacement remote control for TARGA DPV-5300X](#)
- [User Manual](#)