

Mandis DVP1000 Remote Control Instructions

Contents

1

DIGITAL-DYNAMIC DVP 1000

2

Documents / Resources

2.1

References

3

Related Posts



[DIGITAL-DYNAMIC DVP 1000](#)



Original		Substitute	
	Power		Power

	Menu PBC		Menu / Home
	Title		Sound / Title
	Open / Close		AV / Input / RDS
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	10/0		0
	10+		Guide / EPG / -/-
	Clear		Fav / Marker / PC
	Display		Display / Media
	Subtitle		Subtitle / EQ
	Slow		Pause / Step / Freeze
	Program		TV/Radio /
	USB		Picture / Format

	Audio		Audio / Lang I/II
	Mute		Mute / Dimmer
	Repeat		Green / APP / Repeat
	Setup		Yellow / YouTube / Repeat
	Up		Up
	Zoom		Text / Goto
	Play / Pause		Play / Slow
	Left		Left
	Enter		OK
	Right		Right
	Stop		Stop / Hold
	SRC		Back / Return
	Down		Down
	<<		<< / Tune-
	>>		>> / Tune+
	Vol-		Vol-
	Vol+		Vol+
	I<<		I<< / Preset-

	>>		>> / Preset+
--	----	--	---------------



<https://tutti-i-telecomandi.it/it/DIGITAL-DYNAMIC/1065012-95671-telecomando-di-sostituzione-per-DIGITAL-DYNAMIC-DVP1000.html>

Documents / Resources

	Mandis DVP1000 Remote Control [pdf] Instructions DVP1000, DVP1000 Remote Control, Remote Control, Control
---	--

References

- [M Telecomando sostituto di DIGITAL DYNAMIC DVP1000](#)
- [User Manual](#)