



Mandis JX-2022 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis JX-2022 Remote Control Instructions 

Contents

- [1 Mandis JX-2022 Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Product Overview](#)
- [5 Remote Using Instructions](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Mandis JX-2022 Remote Control



Product Information

Specifications

- **Model:** JX-2022
- **Power:** A-B Clear
- Open/Close Time
- Resume Prog Audio

FAQ

- **Q:** Where can I find a replacement remote control for the JX-2022?
 - **A:** You can purchase a replacement remote control for the JX-2022 model from [this link](#).

- **Q:** What does the “Resume Prog Audio” button do?
 - **A:** The “Resume Prog Audio” button allows you to resume playback from where you left off in a program or audio file.

Product Usage Instructions

Power and Controls

- To power on the device, press the “Power” button. The device can also be powered off using the same button.
- The “Open/Close Time” button is used to control the opening and closing of the device’s tray or compartment.
- The “Resume Prog Audio” button allows you to resume playback from where you left off in a program or audio file.

Subtitle and Zoom

- Use the “Subtitle Zoom” button to adjust the size or zoom level of subtitles displayed on the screen.

Numeric Keypad

- The numeric keypad (1-7) can be used for various functions depending on the context or application.

Remote Control Replacement

- If you need a replacement remote control for the JX-2022 model, you can purchase one from [this link](#).

Product Overview



Remote Using Instructions

Original / Recharge

	Power		Power
	A-B		3D
	Clear		Exit
	Open/Close		Eject
	Time		AV
	Resume		Info
	Prog		Sleep
	Audio		Dual
	Subtitle		Subt
	Zoom	 +  Shift + Eject	
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7

	8		8
	9		9
	0/10		0
	10+		Guide
	Ran		TV/R
	OSD		Format
	Return		Back
	Repeat		Text
	Slow		Green
	Menu		Menu
	Angle		Red
	Vol+		Vol +
	Vol-		Vol -
	Mute		Mute
	Surround		Yellow
	L/R		Smart
	Setup		Options

	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter		Ok
	Stop		Stop
	Play		Play
	I<<		I<<
	>>I		>>I
	N/P		Media
	<<		<<
	>>		>>
	Pause/Step		Pause
	PBC		D. Menu
	Title		List

<https://tout-telecommandes.fr/fr/Airis/1056630-82619-telecommande-de-remplacement-pour-Airis-JX-2022.html>



[Mandis JX-2022 Remote Control](#) [pdf] Instructions
JX-2022, JX-2022 Remote Control, Remote Control, Control

References

- [M Télécommande qui remplace AIRIS JX-2022](#)
- [User Manual](#)