



Mandis K40DLJ12F Replacement Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis K40DLJ12F Replacement Remote Control Instructions 

Mandis K40DLJ12F Replacement Remote Control




Contents





- [1 Remote Control Instruction](#)
- [2 Function Button](#)
- [3 Customer Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)



Remote Control Instruction



Function Button

Original	Replacement
 Power	 Power
 Sleep	 Sleep / Timer
 [/≡]	 Setup / OPT /

 Play  Pause  Stop	 Play / Slow  Pause / Step / Freeze  Stop / Hold
 REC  I<<  <<	 Rec / Rec Mode  I<< / Preset-  << / Tune-
 >>  >>I  SUBTL	 >> / Tune+  >>I / Preset+  Subtitle / EQ
 V.O.  FAV  USB	 Picture / Format  Fav / Marker / PC  Shift + 8

	Red		Red / Netflix / Search
	Green		Green / APP / Repeat

Original		Replacement	
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Menu		Menu / Home
	Back		Back / Return
	Up		Up
	Left		Left



OK




Right

INFO



Info



OK



Right

ANGLE



Info / Angle



Down

EXIT



Exit

+

V

Vol+



Down

CLEAR




CANCEL

Exit / Cancel / Clear

+

VOL

Vol+



Mute



CH+



Vol-



Mute / Dimmer



CH+ / Page+



Vol-



EPG



CH-









Guide / EPG / -/--




CH- / Page-



Original	Replacement
1 2 3	TV 11 DVD 22 CD - STB 33
4 5 6	VIDEO 44 TAPE 55 TUNER 66

	7
	8
	9

	7
	8
	9

	TV/Radio
	0
	Recall

	TV/Radio /		
	0		
	+		Shift + Back / Return



Customer Support

[TD-Systems K40DLJ12F](#)

<https://all-remote-controls.co.uk/en/TD-Systems/1066893-94090-replacement-remote-control-for-TD-Systems-K40DLJ12F.html>



Documents / Resources

	Mandis K40DLJ12F Replacement Remote Control [pdf] Instructions K40DLJ12F Replacement Remote Control, K40DLJ12F, Replacement Remote Control, Remote Control, Control
--	--

References

- [User Manual](#)

