



Mandis MED600X3D Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis MED600X3D Remote Control Instructions 

Contents

- [1 Mandis MED600X3D Remote Control](#)
- [2 PRODUCT INFORMATION](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 BUTTON FUNCTION](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)
- [7 Related Posts](#)



Mandis MED600X3D Remote Control



PRODUCT INFORMATION

Specifications

- **Model:** MED600X3D
- **Remote Control Type:** Original/Replacement
- **Power:** Mute, Power
- **TV Controls:** A-B, 1-9
- Pre Ch, Options, TV/R, 3D
- Shift + Play, Media
- 0-9 Numeric Buttons
- Back, Play/Pause, Stop, Vol +/-, Home, Repeat
- Eject
- Smart, Shift + Text
- Up, Left, Ok
- Right, Down, Menu
- Audio Edit, Sleep
- Dual AV, Guide
- Info
- Text + Shift + 1-4, TV/R

Product Usage Instructions

Power and Volume Control

To turn on/off the Mede8er MED600X3D, press the power button. To adjust the volume, use the volume +/- buttons.

TV Controls

The remote control includes A-B and numeric buttons (1-9) for controlling TV functions.

Media Playback

To play/pause media, press the play/pause button. To stop playback, press the stop button. Use the back button to navigate to previous content.

Eject and Repeat

Press the eject button to open the disc tray (if applicable). Use the repeat button to repeat the current media.

Navigation and Selection

Use the arrow buttons (up, down, left, right) to navigate through menus and options. Press the OK button (or enter button) to select an option.

Additional Functions

The remote control includes various additional functions such as smart features, audio editing, sleep mode, dual AV, guide, and info.

FAQ

Where can I find a replacement remote control for the Mede8er MED600X3D?

You can find a replacement remote control for the Mede8er MED600X3D [here](#).

BUTTON FUNCTION

Original		Replacement	
	Power		Power
	Mute		Mute
	★		Pre Ch
	Tools		Options
	TV		TV/R
	Θ		3D
	A-B	 + 	Shift + Play
	(8)		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original		Replacement	
	0		0
	I>		Eject
	Back		Back
	<<		<<
	>>		>>
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	Vol -		Vol -
	Vol +		Vol +
	Home		Smart
	Repeat	 + 	Shift + Text
	Up		Up
	Left		Left
	Enter		Ok

Original	Replacement
 Right	 Right
 Down	 Down
 Menu	 Menu
 i	 Info
 Audio	 Dual
 Edit	 AV
	 Guide
 Sleep	 Sleep
 ←	 Shift + Left
 →	 Shift + Right
 Search	 Shift + TV/R
 Text	 Text
 F1	 Shift + 1
 F2	 Shift + 2
 F3	 Shift + 3
 F4	 Shift + 4

<https://all-remote-controls.co.uk/en/Mede8er/1059659-79123-replacement-remote-control-for-Mede8er-MED600X3D.html>

Documents / Resources



[Mandis MED600X3D Remote Control](#) [pdf] Instructions
MED600X3D Remote Control, MED600X3D, Remote Control, Control

References

- [Replacement remote control for MEDE8ER MED600X3D](#)
- [User Manual](#)