



Mandis MED600X3D Replacement Remote Control Instruction Manual

[Home](#) » [Mandis](#) » **Mandis MED600X3D Replacement Remote Control Instruction Manual** 

Mandis MED600X3D Replacement Remote Control Instruction Manual



Contents

- [1 Remote Control Buttons Instruction](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

Remote Control Buttons Instruction








Original	Replacement	Original	Replacement
	Power		Power
	Mute		Mute
	★		Pre Ch
	Tools		Options
	TV		TV/R
	Θ		3D
	A-B		Shift + Play
	(8)		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	I>		Eject
	Back		Back
	<<		<<
	>>		>>
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	Vol -		Vol -
	Vol +		Vol +
	Home		Smart
	Repeat		Shift + Text
	Up		Up
	Left		Left
	Enter		Ok






Original	Replacement



	Audio		Dual
	Edit		AV
			Guide
	Sleep		Sleep
	←•		Shift + Left
	•→		Shift + Right
	Search		Shift + TV/R
	Text		Text

Mediatek MED60
OX3D



	F1		Shift + 1
	F2		Shift + 2
	F3		Shift + 3
	F4		Shift + 4

<https://all-remote-controls.co.uk/en/Mede8er/1059659-79123-replacement-remote-control-for-Mede8er-MED600X3D.html>



Documents / Resources

	Mandis MED600X3D Replacement Remote Control [pdf] Instruction Manual MED600X3D Replacement Remote Control, MED600X3D, Replacement Remote Control, Remote Control, Control
---	--

References

- [M Replacement remote control for MEDE8ER MED600X3D](#)
- [User Manual](#)