



Mandis Mede8er MED600X3D Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis Mede8er MED600X3D Remote Control Instructions 

Contents

- [1 Mandis Mede8er MED600X3D Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Product Overview](#)
- [5 Remote Using Instructions](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Mandis Mede8er MED600X3D Remote Control



Product Information

Specifications

- **Model:** MED600X3D
- **Remote Control Type:** Replacement
- **Power Options:** Power, Mute
- **TV Controls:** A-B, 1-9
- **Media Controls:** Play/Pause, Stop, Volume, Repeat
- **Additional Controls:** Back, Eject, Smart, Text, Menu, Info, Dual AV, Guide, Sleep

Frequently Asked Questions

- **Where can I find a replacement remote control for Mediatek MED600X3D?**
 - You can find a replacement remote control for Mediatek MED600X3D at the following link: [Replacement](#)

Product Usage Instructions

Powering On/Off

- To power on the Mede8er MED600X3D, press the Power button on the remote control.
- To power off, press and hold the Power button until the device shuts down.

Muting Sound

- To mute the sound, press the Mute button on the remote control.
- To unmute, press the Mute button again.

TV Controls

- The remote control features A-B buttons for TV channel selection.
- Press the corresponding number buttons (1-9) to directly select a specific TV channel.

Media Controls

The remote control provides various media controls for playback:

- **Play/Pause:** Press the Play/Pause button to start or pause media playback.
- **Stop:** Press the Stop button to stop media playback.
- **Volume:** Use the Volume + and – buttons to adjust the audio volume.
- **Repeat:** Press the Repeat button to toggle repeat mode for media playback.

Additional Controls

The remote control includes additional controls for navigation and settings:


- **Back:** Press the Back button to go back to the previous menu or screen.
- **Eject:** Use the Eject button to eject discs (if applicable).
- **Smart:** The Smart button provides access to smart features or apps (if available).
- **Text:** Press the Text button to display teletext or additional text information (if supported).
- **Menu:** Use the Menu button to access the main menu or settings.
- **Info:** Press the Info button to display detailed information about the current media or program.
- **Dual AV:** Use the Dual AV button to switch between different audio/video sources.
- **Guide:** Press the Guide button to access an electronic program guide (EPG) (if supported).
- **Sleep:** The Sleep button allows you to set a sleep timer for automatic device shutdown.

Product Overview



Remote Using Instructions

Original / Replacement

	Power		Power
	Mute		Mute
	★		Pre Ch
	Tools		Options
	TV		TV/R
	Θ		3D
	A-B		Shift + Play
	(8)		Media
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

	0		0
	I>		Eject
	Back		Back
	<<		<<
	>>		>>
	Play / Pause		Play
	Play / Pause		Pause
	Stop		Stop
	I<<		I<<
	>>I		>>I
	Vol -		Vol -
	Vol +		Vol +
	Home		Smart
	Repeat		Shift + Text
	Up		Up
	Left		Left
	Enter		Ok

	Right		Right
	Down		Down
	Menu		Menu
	i		Info
	Audio		Dual
	Edit		AV
			Guide
	Sleep		Sleep
	←•		Shift + Left
	•→		Shift + Right
	Search		Shift + TV/R
	Text		Text
	F1		Shift + 1
	F2		Shift + 2
	F3		Shift + 3
	F4		Shift + 4

<https://all-remote-controls.co.uk/en/Mede8er/1059659-79123-replacement-remote-control-for-Mede8er-MED600X3D.html>

Documents / Resources

	Mandis Mede8er MED600X3D Remote Control [pdf] Instructions MED600X3D, Mede8er MED600X3D Remote Control, Mede8er MED600X3D, Remote Control, Control, Control
---	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)