



Mandis MIIA RCMT49KS02 V2 Remote Control Instruction Manual

[Home](#) » [Mandis](#) » Mandis MIIA RCMT49KS02 V2 Remote Control Instruction Manual 

Contents

- [1 Mandis MIIA RCMT49KS02 V2 Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 OVERVIEW](#)
- [5 Replacement Parts](#)
- [6 BUTTON DESCRIPTIONS](#)
- [7 Documents / Resources](#)
 - [7.1 References](#)
- [8 Related Posts](#)



Mandis MIIA RCMT49KS02 V2 Remote Control



Product Information

Specifications

- Model: MIIA RCMT49KS02 V2
- Original remote control for MIIA devices
- Features: Power, Mute, Sleep, Channel List, Recharge, Dimmer, Recall, Source Up, Audio/Nicam, OK, Exit, Menu, Volume control, Mouse On/Off, P.Mode, S.Mode, AV/Input/RDS Up, Audio/Lang I/II, D.Menu/Top, CH+/ePnauge+, Vol-, Picture/Format, Sound/Title, Display Fav TXT, Sub/Index EPG/S.Page, Stop, Hold/Aspect, Play/Pause, Reveal/Antena, Red/Green/Yellow/Blue buttons
- Compatible with MIIA RCMT49KS02 V2
- Product URL: <https://tout-telecommandes.fr/fr/MIIA/1066695-93194-telecommande-de-remplacement-pour-MIIA-RCMT49KS02-V2.html>

Product Usage Instructions

- Power and Basic Controls
To power on or off the device, press the “Power” button. To mute or unmute the sound, press the “Mute” button. To adjust the brightness level of the display, use the “Dimmer” button. Numeric Keypad and Navigation The numeric keypad can be used to directly input channel numbers or navigate through menus. Press the

corresponding number to access the desired channel or menu option.

- Channel List and Recall

The “CH.List” button allows you to view and navigate through the list of available channels. The “Recall” button can be used to quickly switch between the current and previous channel.

- Sleep Timer

Press the “Sleep/Timer” button to activate the sleep timer function. Use the “+” and “-” buttons to adjust the desired sleep time. The device will automatically turn off after the set time.

- Source Selection

Use the “Source Up” button to cycle through available input sources. Press the “OK” button to confirm the selected source.

- Volume Control

Adjust the volume level using the “Vol+” and “Vol-” buttons. Pressing the “Mute” button will temporarily mute the sound.

Frequently Asked Questions (FAQ)

- Q: What is the model of this remote control?
- A: The model of this remote control is MIIA RCMT49KS02 V2.
- Q: What devices is this remote control compatible with?
- A: This remote control is compatible with MIIA devices.
- Q: Where can I find more information about this product?
- A: More information about this product can be found on the product page at <https://tout-telecommandes.fr/fr/MIIA/1066695-93194-telecommande-de-remplacement-pour-MIIA-RCMT49KS02-V2.html>.

OVERVIEW



Replacement Parts

Original

Recharge

	Power		Power
	Mute		Mute / Dimmer
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	Recall		Back / Return
	0		0
	Sleep		Sleep / Timer
		 + 	Shift + 1
		 + 	Shift + 2
	CH.List		Smart / List

	Source		AV / Input / RDS
	Up		Up
	Audio / Nicam		Audio / Lang I/II
	Left		Left
	OK		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Menu		Menu / Home
	Vol+		Vol+
	Mouse On/Off		D.Menu / Top
	CH+		CH+ / Page+
	Vol-		Vol-
	Home		Shift + Menu /
	CH-		CH- / Page-
	P.Mode		Picture / Format
	S.Mode		Sound / Title

	Display		Display / Media
	Fav		Fav / Marker / PC
	TXT		Text / Goto
	Sub / Index		Subtitle / EQ
	EPG / S.Page		Guide / EPG / -/--
	Size		Zoom / Size
	Stop		Stop / Hold
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Hold / Aspect		Setup / OPT /
	Hold / Aspect	 + 	Shift + Stop /
	Play / Pause		Play / Slow
	<<		<< / Tune-
	>>		>> / Tune+
	Reveal / Antenna		TV/Radio /
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random

BUTTON DESCRIPTIONS



<https://tout-telecommandes.fr/fr/MIIA/1066695-93194-telecommande-de-remplacement-pour-MIIA-RCMT49KS02-V2.html>

Documents / Resources



[Mandis MIIA RCMT49KS02 V2 Remote Control](#) [pdf] Instruction Manual
MIIA RCMT49KS02 V2 Remote Control, MIIA RCMT49KS02 V2, Remote Control, Control

References

- [M Télécommande qui remplace MIIA RCMT49KS02 V2](#)
- [User Manual](#)