



Mandis MSL210 Replacement Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis MSL210 Replacement Remote Control Instructions 

Mandis MSL210 Replacement Remote Control Instructions



Contents

[1 Remote Control](#)

[Instructions](#)

[2 Function Button](#)

[3 Customer Support](#)

[4 Documents / Resources](#)

[4.1 References](#)




[5 Related Posts](#)

Remote Control Instructions















Function Button

Original	Replacement
----------	-------------

 Standby	 Power
 Mute	 Mute / Dimmer
 Search	 Red / Netflix / Search
 CD/USB	 Eject / Surround
 Source	 AV / Input / RDS
 Repeat	 Green / APP / Repeat
 Intro	 Shift + OK
 Random	 Blue / Prime Video / Random
 Stop	 Stop / Hold

 CH+	 CH+ / Page+
 >>	 >> / Preset+
 CH-	 CH- / Page-
 <<	 << / Preset-
 <</FF-	 << / Tune-
 >>/FF+	 >> / Tune+
 Play/Pause	 Play / Slow
 DSP	 D.Menu / Top
Original	Replacement

 Loudness	 Sound / Title
 Memory	 Picture / Format
 Function	 OK
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6

 7  8  9	 7  8  9
 0  +10  Prog	 0  Guide / EPG / +/-  TV/Radio /
 Vol-  Vol+	 Vol-  Vol+



Customer Support

[Nevir NEVIR012](#)

<https://tout-telecommandes.fr/fr/Nevir/1065517-79618-telecommande-de-remplacement-pour-Nevir-Nevir012.html>



Documents / Resources

	Mandis MSL210 Replacement Remote Control [pdf] Instructions MSL210 Replacement Remote Control, MSL210, Replacement Remote Control, Remote Contr ol, Control
	Mandis MSL210 Replacement Remote Control [pdf] Instructions MSL210 Replacement Remote Control, MSL210, Replacement Remote Control, Remote Contr ol, Control

References

-  [Replacement remote control for NEVIR Nevir012](#)
- [User Manual](#)