



Mandis RC 1080 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis RC 1080 Remote Control Instructions 



Contents


[1 RC 1080 Remote Control](#)

[2 Documents / Resources](#)

[2.1 References](#)

[3 Related Posts](#)

RC 1080 Remote Control



Original	Replacement	Original	Replacement
	Power		5
	Red/Sound		6
	Green/Picture		7
	Yellow/Feature		8
	Blue/Install		9
	[=]		0
	[=O]		P<P
	[=+]		-/--
	[=X]		Vol+
	[.=]/[I/■]		Vol-
	[=◆]/[■]		Mute
	[=?]/↓		P+
	[=i]/↑		P-
	1		I-II
	2		[i]
	3		TV
	4		AV



