



Mandis RC18T1-27 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis RC18T1-27 Remote Control Instructions 

Mandis RC18T1-27 Remote Control Instructions



Contents

- [1 Remote Control](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)


Remote Control










On / Off



Power

 Mute All	 Audio / Lang I/II
 Mute	 Mute / Dimmer
 CD-DVD	 +  + Shift + 3
 FM-AM	 +  + Shift + 6
 AUX	 +  + Shift + 7
 TV	 +  + Shift + 1
 CBL-SAT	 +  + Shift + 0
 VCR	 +  + Shift + 4
 Up / Tune +	 Up
 DVD Menu	 D.Menu / Top
 Settings	 Setup / OPT /
 Left	 Left
 Enter	 OK
 Right	 Right
 Guide	 Guide / EPG / -/-

 System	 Menu / Home
 Down / Tune –	 Down
 Exit	 Exit / Cancel / Clear
 Track/Chap./CH +	 CH+ / Page+
 Volume +	 Vol+
 Track/Chap./CH –	 CH- / Page
 Volume –	 Vol-
 Stop	 Stop / Hold
 Pause	 Pause / Step / Freeze
 Play	 Play / Slow
 I<< / Seek –	 I<< / Preset-
 I<< / Seek –	 << / Tune-
 >>I / Seek +	 >> / Tune+
 >>I / Seek +	 >>I / Preset+

 Shuffle / Presets <-	 Red / Netflix / Search
 Repeat / Presets ->	 Blue / Prime Video / Random
 1	 1
 2	 2
 3	 3
 4	 4
 5	 5
 6	 6
 7	 7
 8	 8
 9	 9
 0	 0
 Info	 Info / Angle

<https://tout-telecommandes.fr/fr/BOSE/1060332-78771-telecommande-de-remplacement-pour-BOSE-RC18T1-27.html>

Documents / Resources



[Mandis RC18T1-27 Remote Control](#) [pdf] Instructions
RC18T1-27 Remote Control, RC18T1-27, Remote Control

References

- [M Télécommande qui remplace BOSE RC18T1-27](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.