



Mandis RC4810 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis RC4810 Remote Control Instructions 



Contents

1 RC4810 Remote Control

2 Documents / Resources

2.1 References

3 Related Posts

RC4810 Remote Control



Original	Replacement	Original	Replacement
	Power		Power
	Source		TV
	Vol+		Recall
	Vol-		World
	Mute		Menu
	PR+		Exit
	PR-		Back
	1		i/Info
	2		Guide
	3		[=]/Text
	4		* / O
	5		* / O .
	6		Lang
	7		[=] .
	8		[- O -]
	9		Red
	0		Green
			Yellow





Mandis RC4810 Remote Control [pdf] Instructions
 RC4810, RC4810 Remote Control, Remote Control, Control

- [!\[\]\(e3f443b9578f18c0325a655158a32b0d_img.jpg\) Replacement remote control for RC4810 \(30087841\)](#)
- [User Manual](#)