

Mandis RC675 Remote Control Instructions

Mandis RC675 Remote Control Instructions

Remote Control Using Instructions

Original	Replacement
Play	Play / Slow
>>	>> / Tune+
Pause	Pause / Step / Freeze
Rec	Rec / Rec Mode
Stop	Stop / Hold

Kathrein RC675

<https://all-remote-controls.co.uk/en/Kathrein/1066717-90534-replacement-remote-control-for-Kathrein-RC675.html>

Contents

[1 Documents / Resources](#)

[1.1 References](#)

Documents / Resources

	Mandis RC675 Remote Control [pdf] Instructions RC675 Remote Control, RC675, Remote Control, Control
---	--

References

-  [Replacement remote control for KATHREIN RC675](#)
- [User Manual](#)

