



Mandis RCU-540 Replacement Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis RCU-540 Replacement Remote Control Instructions 



Contents

- [1 RCU-540 Replacement Remote Control](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

RCU-540 Replacement Remote Control

[Ferguson RCU-540](#)



Originale	Sostituto	Originale	Sostituto
	Power		Power
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Info		Info
	Guide		Guide
	Mute		Mute
	Vol+		Vol +
	Vol-		Vol -
	CH+		Ch +
	CH-		Ch -
	>>I		>>I
	I<<		I<<
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/List		Ok
	Menu		Menu
	Back		Back
	Red/Text		Red
	Green/Audio		Green
	Yellow/Sub		Yellow
	Blue/Find		Blue
	Play		Play
	Pause		Pause



<https://tutti-i-telecomandi.it/it/Ferguson/1058143-20273-telecomando-di-sostituzione-per-Ferguson-RCU540.html>




Originale	Sostituto	Originale	Sostituto
	>>		>>
	Stop		Stop
	Rec		Rec
	PVR		Smart
	FAV		Pre Ch
	[+]/Ratio		3D
	Page Up		Shift + Up
	Page Down		Shift + Down
	[v]/Edit		Media
	F1/Tv/Radio		TV/R
	F2/Input		AV
	F3		Subt
	F4		Options



<https://tutti-i-telecomandi.it/it/Ferguson/1058143-20273-telecomando-di-sostituzione-per-Ferguson-RCU540.html>

Documents / Resources



[Mandis RCU-540 Replacement Remote Control](#) [pdf] Instructions

RCU-540 Replacement Remote Control, RCU-540, Replacement Remote Control, Remote Control, Control

References

- [M Telecomando sostituto di FERGUSON RCU540](#)
- [User Manual](#)