



Mandis REMCON755 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis REMCON755 Remote Control Instructions 

Contents

- [1 Mandis REMCON755 Remote Control Instructions](#)
- [2 Clarke Tech REMCON755](#)
- [3 Clarke Tech REMCON755](#)
- [4 Read More About This Manual & Download PDF:](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)

Mandis REMCON755 [Remote](#) Control Instructions




Clarke Tech REMCON755



Original	Replacement	Original	Replacement
	Power		Up
	Mute / Dimmer		CH+ / Page+
	1		Exit / Cancel / Clear
	2		Left
	3		Vol-
	4		OK
	5		Right
	6		Vol+
	7		Down
	8		CH- / Page-
	9		Smart / List
	TV/Radio /		Shift + CH+ /
	TV/Sat		>> / Preset+
	Display / Media		Pause / Step / Freeze
	Guide / EPG / -/-		Picture / Format
	Info / Angle		Shift + CH- /
	Menu / Home		I<< / Preset-



Clarke Tech REMCON755





- [Quals+, Privacy Policy](#)