



Mandis SOGO001 Remote Control Instruction Manual

[Home](#) » [Mandis](#) » Mandis SOGO001 Remote Control Instruction Manual 



Contents

- [1 SOGO001 Remote Control](#)
- [2 Documents / Resources](#)
 - [2.1 References](#)
- [3 Related Posts](#)

SOGO001 Remote Control



Originale

Sostituto

	Power		Power
	Open/Close		Eject / Surround
	Language	 + 	Shift + Audio / Lang I/II
	1		1
	2		2
	3		3
	Angle		Info / Angle
	4		4
	5		5
	6		6
	Subtitle		Subtitle / EQ
	7		7
	8		8
	9		9
	Return		Back / Return
	Time		Sleep / Timer
	10+		Guide / EPG / -/--

Originale

Sostituto

	Vol-		Vol-
	Audio		Audio / Lang I/II
	Slow	 + 	Shift + Play /
	OSD		Display / Media
	<</REV		<< / Tune-
	>>/FWD		>> / Tune+
	I<</Prev		I<< / Preset-
	>>I/Next		>>I / Preset+
	Stop		Stop / Hold
	Pause		Pause / Step / Freeze
	Play		Play / Slow
	Key+		CH+ / Page+
	Key-		CH- / Page-
	3D		Picture / Format
	Video	 + 	Shift + 4



Originale		Sostituto	
	0		0
	Setup		Setup / OPT /
	Up		Up
	Title		Sound / Title
	Left		Left
	Enter		OK
	Right		Right
	Root		Text / Goto
	Down		Down
	Zoom		Zoom / Size
	Prog		TV/Radio /
	PBC		Smart / List
	Ran		Blue / Prime Video / Random
	Vol+		Vol+
	Mute		Mute / Dimmer
	Repeat		Green / APP / Repeat
	A-B		Yellow / YouTube / Repeat

<https://tutti-i-telecomandi.it/it/Sogo/1067331-94565-telecomando-di-sostituzione-per-Sogo-SOGO001.html>

Documents / Resources

	Mandis SOGO001 Remote Control [pdf] Instruction Manual SOGO001, SOGO001 Remote Control, Remote Control, Control
---	--

References

- [User Manual](#)