



Mandis Stream-System BM32C1 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis Stream-System BM32C1 Remote Control Instructions 

Mandis Stream-System BM32C1 Remote Control



Contents

- [1 Product Overview](#)
- [2 Buttons Descriptions](#)
- [3 Customers Support](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)




Product Overview







Buttons Descriptions

Original	Recharge
----------	----------



	Power		Power
	16:9 Wide		Format
	Red		Red
	Green / Subtitle		Green
	Green / Subtitle		Subt
	Yellow / FAV		Yellow
	Yellow / FAV	  	Shift + Pre Ch
	Blue / EPG		Blue
	Blue / EPG	  	Shift + Guide

HOLD ⏮	I<< / Hold	⏮	I<<
LIST ⏭	>>I / List	DISC NAV LIST	List
LIST ⏭	>>I / List	⏭	>>I
LANGUAGE ⏮	<< / Language	SOUND DUAL	Dual
LANGUAGE ⏮	<< / Language	⏮	<<
RADIO ⏭	>> / Radio	⏭	>>
RADIO ⏭	>> / Radio	SEARCH TV/R	TV/R
INDEX ▶	Play / Index	PLAY MODE ▶	Play
ZOOM ⏸	Pause / Zoom	⏸	Pause
ZOOM ⏸	Pause / Zoom	ZOOM ⏏	Eject
REVEAL ■	Stop / Reveal	■	Stop


	Back / TTX
	Back / TTX
	Info


	Back
	Text
	Info


	Rec
	L / R
	Smart S

	Rec
 + 	Shift + Dual
	Smart








	Up
	Right
	Down

	Up
	Right
	Down

	Left
	OK
	Source

	Left
	Ok
	AV

MENU Menu	TOP MENU MENU Menu
+ VOL Vol +	+ VOL Vol +
VOL - Vol -	VOL - Vol -
F1 F1	APP MEDIA Media
MUTE Mute	MUTE Mute
+ CH CH +	+ CH Ch +
CH - CH -	CH - Ch -
1 ABC 1	1 1
2 DEF 2	2 2
3 GHI 3	3 3
4 JKL 4	4 4

	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Recall		Pre Ch
	Guide		Guide

Customers Support

[Stream-System BM32C1](#)

<https://tout-telecommandes.fr/fr/Stream-System/1058820-82675-telecommande-de-remplacement-pour-Stream-System-BM32C1.html>



Documents / Resources



[Mandis Stream-System BM32C1 Remote Control](#) [pdf] Instructions
Stream-System BM32C1, Stream-System BM32C1 Remote Control, Remote Control, Control

References

- [M Télécommande qui remplace STREAM SYSTEM BM32C1](#)
- [User Manual](#)