



Mandis Technics-RAKSU129WH Replacement Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis Technics-RAKSU129WH Replacement Remote Control Instructions 

Mandis Technics-RAKSU129WH Replacement Remote Control



Contents


- [1 Remote Control Replacement Instructions](#)
- [2 Customer Support](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)
- [4 Related Posts](#)

Remote Control Replacement Instructions




Original


Re-change



POWER



AUDIO OFF



MUTING



TAPE 1



TAPE 2



Power



Mute / Dimmer



+



Shift +
Mute /
Dimmer



+




Shift +
4




+



Shift +
5



CD



TUNER



DCC



AUX



PHONO



+



Shift +
3



+



Shift +
6



Text / Goto



+





Shift +
7




Audio / Lang I/II


 PRESET -	 Shift + I<< / Preset-
 PRESET -	 Subtitle / EQ
 PRESET +	 Shift + >>I / Preset+
 PRESET +	 Eject / Surround
 BAND	 Display / Media
 Deck 1/2	 Shift + 1
 1	 1

Original	Re-change
----------	-----------


	2		2
	3		3
	DISC		Smart / List
	4		4
	5		5
	6		6

	+10
	7
	8
	9
	0
	I<<


	Guide / EPG / -/--
	7
	8
	9
	0
	I<< / Preset-




>>I



<<



>>



PAUSE



STOP




>>I / Preset+



<< / Tune-



>> / Tune+







Pause / Step /
Freeze



Stop / Hold





Original	Re-change
 Play Reverse	 +  Shift + Play /
 PLAY	 Play / Slow
 VOLUME -	 Vol-
 VOLUME -	 +  Shift + Vol-
 VOLUME +	 Vol+
 VOLUME +	 +  Shift + Vol+



Customer Support

[Technics RAK-SU 129 WH](https://tout-telecommandes.fr/fr/Technics/1057692-21622-telecommande-de-remplacement-pour-Technics-RAKSU129WH.html)

<https://tout-telecommandes.fr/fr/Technics/1057692-21622-telecommande-de-remplacement-pour-Technics-RAKSU129WH.html>



Mandis shop

Documents / Resources



[Mandis Technics-RAKSU129WH Replacement Remote Control](#) [pdf] Instructions
Technics-RAKSU129WH Replacement Remote Control

References

- [M Télécommande qui remplace TECHNICS RAKSU129WH](#)
- [User Manual](#)