



Mandis TIMER-DIG-6 CTS Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis TIMER-DIG-6 CTS Remote Control Instructions 

Contents

- [1 Mandis TIMER-DIG-6 CTS Remote Control](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 function](#)
- [5 Documents / Resources](#)
 - [5.1 References](#)
- [6 Related Posts](#)

Mandis

Mandis TIMER-DIG-6 CTS Remote Control



Product Information

Specifications

- Product Name: Timer Dig 6 CTS
- Model Number: CT01
- Product Type: Replacement Remote Control
- Compatibility: Timer Dig 6 CTS
- Website:

<https://all-remote-controls.co.uk/en/Timer-Dig-6/1064815-95434-replacement-remote-control-for-Timer-Dig-6-CTS.html>

Product Usage Instructions

Power Reset

To perform a power reset on the Timer Dig 6 CTS remote control, follow these steps:

1. Press and hold the Power button for 5 seconds.
2. The remote control will reset and turn off.
3. Release the Power button.
4. Wait for a few seconds, then press the Power button again to turn on the remote control.

Power Guide / EPG / -/-

To access the Power Guide or EPG (Electronic Program Guide) on the Timer Dig 6 CTS remote control, follow these steps:

1. Press the Power Guide or EPG button on the remote control.
2. Use the number buttons (1-9, 0) to navigate through the guide.
3. Press the Mute button to shift the interval of the guide.
4. Press the Clock Up button to change the display mode.

function



Original		Replacement	
	Power		Power
	Reset		Guide / EPG / -/--
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	Mute		Mute / Dimmer
	Shift		Smart / List
	Interval		Display / Media
	Clock		Fav / Marker / PC
	Up		Up

Original		Replacement	
	Left		Left
	Enter		OK
	Right		Right
	Down		Down
	Exit		Exit / Cancel / Clear
	Edit		Back / Return
	F1		Sound / Title
	F2		Audio / Lang I/II
	F3		Subtitle / EQ
	F4		Eject / Surround
	F5		Picture / Format
	F6		Zoom / Size
	F7		Sleep / Timer
	F8		TV/Radio /
	F9		D.Menu / Top
	F10		Setup / OPT /
	F11		Text / Goto

<https://all-remote-controls.co.uk/en/Timer-Dig-6/1064815-95434-replacement-remote-control-for-Timer-Dig-6-CTS.html>

Documents / Resources

	Mandis TIMER-DIG-6 CTS Remote Control [pdf] Instructions TIMER-DIG-6 CTS Remote Control, TIMER-DIG-6 CTS, Remote Control, Control
	Mandis TIMER-DIG-6 CTS Remote Control [pdf] Instructions TIMER-DIG-6 CTS Remote Control, TIMER-DIG-6 CTS, Remote Control, Control

References

- [M Replacement remote control for TIMER-DIG-6 CTS](#)
- [User Manual](#)