



Mandis TM1850A Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis TM1850A Remote Control Instructions 



Contents

[1 TM1850A Remote Control](#)

[2 Documents / Resources](#)

[2.1 References](#)

TM1850A Remote Control



[Samsung Smart-TV](#)



Original	Recharge
Power	Power
123 / keypad	Eject / Surround
Extra	D.Menu / Top
Up	Up
Left	Left
OK	OK
Right	Right
Down	Down
Return	Back / Return
Vol Up	Vol+
Home / Hub	Smart / List
CH Up	CH+ / Page+
Vol Down	Vol-
CH Down	CH- / Page-
Play / Pause	Shift + Play /
Mute	Mute / Dimmer
Play	Play / Slow

Original	Recharge
Pause	Pause / Step / Freeze
Stop	Stop / Hold
Rec	Rec / Rec Mode
<<	<< / Tune-
>>	>> / Tune+
I<<	I<< / Preset-
>>I	>>I / Preset+
S.Mode	Sound / Title
AD	Audio / Lang I/II
AD / Subt.	Subtitle / EQ
Picture	Picture / Format
P.Size	Zoom / Size
Sleep	Sleep / Timer
Auto Prog	TV/Radio /
Tools	Setup / OPT /
TTX/MIX	Text / Goto
Source	AV / Input / RDS



Original	Recharge
Menu	Menu / Home
Info	Info / Angle
Exit	Exit / Cancel / Clear
CH List	Display / Media
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Guide	Guide / EPG / -/-
0	0
Fav CH	Fav / Marker / PC
Search	Shift + Yellow / YouTube / Repeat

Original	Recharge
Prime Video	Shift + Blue / Prime
Rakuten Tv	Shift + Green / APP /
Netflix	Shift + Red / Netflix /
Still	Shift + Pause / Step /
Dual I-II	Shift + Audio / Lang I/II
Add / Del	Shift + Eject / Surround
TV / DTV	Shift + TV/Radio / Program
E-Manual	Shift + OK
Media P.	Shift + Display / Media
-/-	Shift + Guide / EPG / -/-
PRE-CH	Shift + Fav / Marker / PC
Red	Red / Netflix / Search
Yellow	Yellow / YouTube / Repeat
Blue	Blue / Prime Video / Random
Green	Green / APP / Repeat



<https://tout-telecommandes.fr/fr/Samsung/1037832-78618-telecommande-de-remplacement-pour-Samsung-TM1850A-BN59-01259B.html>



Documents / Resources

	Mandis TM1850A Remote Control [pdf] Instructions TM1850A Remote Control, TM1850A, Remote Control, Control
	Mandis TM1850A Remote Control [pdf] Instructions TM1850A Remote Control, TM1850A, Remote Control, Control

References

- [M Télécommande qui remplace SAMSUNG TM1850A \(BN59-01259B\)](#)
- [User Manual](#)