



Mandis VES-01 Remote Control Instructions

[Home](#) » [Mandis](#) » Mandis VES-01 Remote Control Instructions 

Contents

- [1 Mandis VES-01 Remote Control Instructions](#)
- [2 Product Information](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 Additional Features](#)
- [6 NAVIGATION BARS](#)
- [7 OVERVIEW](#)
- [8 BUTTON FUNCTIONS](#)
- [9 Frequently Asked Questions](#)
- [10 Documents / Resources](#)
 - [10.1 References](#)



Mandis VES-01 Remote Control Instructions



Product Information

Specifications

- **Model:** VES-01
- **Power:** 2 AAA batteries (not included)
- **Compatibility:** Original and Replacement remote controls
- **Dimensions:** (L) x (W) x (H)

Product Usage Instructions

- **Power**
To turn on the TV/AV device, press the **Power** button. To turn off the device, press the **Power** button again.
- **Mute**
To mute/unmute the sound, press the **Mute** button.
- **TV/AV**
To switch between TV and AV modes, press the **TV/AV** button.
- **Lock Text**
To lock/unlock text on the screen, press the **Lock Text** button.
- **List Text**
To access the text list, press the **List Text** button.
- **Guide**
To open the TV guide, press the **Guide** button.

Aspect Ratio

To change the aspect ratio of the screen, press the appropriate buttons:

- **QV Aspect:** Quick View Aspect ratio

- **Subcode Mix:** Subcode Mix aspect ratio

Sleep Timer

To set the sleep timer, press the **Sleep** button. Use the arrow keys to adjust the timer and press **Ok** to confirm.

Volume and Channel Control

Use the following buttons for volume and channel control:

- **Volume Up/Down:** Adjust the volume level
- **Channel Up/Down:** Change the channel

Menu

To access the menu options, press the **Menu** button. Use the arrow keys to navigate through the menu and press **Ok** to select an option.

Additional Features

The remote control also offers additional features such as:

- **Subtitles:** Use the **Subt** button to enable/disable subtitles
- **Dual Audio:** Use the **Dual** button to switch between dual audio tracks
- **Info:** Press the **Info** button to display information about the current program
- **Stop:** Press the **Stop** button to stop playback
- **Options:** Access additional options by pressing the **Options** button

NAVIGATION BARS



OVERVIEW



BUTTON FUNCTIONS

VES-01

Original

Replacement

	Power		Power
	Mute		Mute
	TV / AV		AV
	?		Smart
	Lock		List
	Text		Text
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9
	0		0
	-/--		Guide

	QV		Pre Ch
	Aspect		Format
	Subcode		Subt
	Mix	 + 	Shift + Text
	Cancel		Exit
	Red / Picture		Red
	Red / Picture	 + 	Shift + Format
	Green / Sleep		Green
	Green / Sleep		Sleep
	Yellow / Timer		Yellow
	Yellow / Timer		TV/R
	Blue / Sound		Blue
	Blue / Sound	 + 	Shift + Dual
	Reveal		Info
	Hold		Stop
	→ S ←		Dual
	→ P ←		Options
	Up / P +		Ch +
	Up / P +		Up
	Down / P -		Ch -
	Down / P -		Down
	Right / V +		Right
	Right / V +		Vol +
	Left / V -		Left
	Left / V -		Vol -
	Menu		Menu
	Menu		Ok

Frequently Asked Questions

How do I replace the batteries?

To replace the batteries, open the battery compartment on the back of the remote control. Remove the old batteries and insert two AAA batteries, making sure to match the polarity +/- correctly. Close the battery compartment.

How do I pair the replacement remote control?

The replacement remote control should work automatically without the need for pairing. Simply insert the batteries and use it as you would with the original remote control.

Where can I find the user manual for the VES-01 remote control?

You can find the user manual for the VES-01 remote control on the following website [VES-01 User Manual](#)

Documents / Resources

	Mandis VES-01 Remote Control [pdf] Instructions VES-01 Remote Control, VES-01, Remote Control, Control
	Mandis VES-01 Remote Control [pdf] Instructions VES-01 Remote Control, VES-01, Remote Control, Control
	Mandis VES-01 Remote Control [pdf] Instructions VES-01 Remote Control, VES-01, Remote Control, Control
	Mandis VES-01 Remote Control [pdf] Instruction Manual VES-01 Remote Control, VES-01, Remote Control, Control

References

- [User Manual](#)