




Home » Marelux » MARELUX Remote Shutter Module User Manual 🏗





Contents [hide]

- 1 Introduction
- 2 Tech Specs
- 3 Parts Illustration
- 4 Installation
- 5 Usage
- 6 Customer Support
- 7 Documents / Resources
 - 7.1 References

Introduction

Please read this user manual carefully before starting to use the product, and use the product properly based on the thorough understanding of this user manual.

Tech Specs

Material: POM

Dimensions: 72mm(W) 30mm(H) 30mm(D)

Weight in Air: 37.5g


Effective receiving distance: 10 meters

Optical signal receiving angle: 140 degrees

Equipped with a built-in battery that supports charging via the USB-C interface.


Parts Illustration






Shutter release cable port

Installation



For the Wireless Shutter Module: Insert the shutter release cable, then install the module into the bottom slot of the housing quick-release plate.



Secure the module with screws. Insert the shutter release cable into the camera and then install the camera into the housing.

Usage

- 1. Press the power button to turn the device on or off.
- 2. Use the 42703 Artemis 4500 RMT to remotely control the camera shutter.
- 3. When the battery is low, connect the USB Type-C cable to the USB Type-C charging port for charging.

Customer Support

https://www.marelux.co/

MARELUX

Documents / Resources



MARELUX Remote Shutter Module [pdf] User Manual 63d5e17e3f, Remote Shutter Module, Shutter Module, Module

References

- User Manual
 - 63d5e17e3f, Marelux, Module, Remote Shutter Module, Shutter
- Marelux Module

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name		
Email		
<u> </u>		
Website		
☐ Save my name, email, and website in this browser for the next time I com	ment.	
Post Comment		
Search:		
e.g. whirlpool wrf535swhz	Search	

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.