

MARMITEK Push LE WHT/BLK Smart Zigbee Switch User Guide

Home » MARMITEK » MARMITEK Push LE WHT/BLK Smart Zigbee Switch User Guide 🖫





Contents

- 1 Package content
- 2 Safety Instructions
- 3 Installation of the Smart me app
- 4 Installation of the Push LE
- **5 Technical specifications**
- **6 Declaration of Conformity**
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Package content

1x smart switch

1x CR2430 battery

1x 3M adhesive tape

1x quick guide

This product requires a Zigbee gateway (sold separately).

Marmitek Smart me app



http://www.marmitek.com/media/qr/Smart_me_ug_store_aa_01.html

Multi language user guide



http://www.marmitek.com/media/qr/ple_ug_ma_aa_01.html

Please read these instructions thoroughly before you use the device and keep them for future reference. **Only for indoor use.**


- Do not expose the product to extremely high or low temperatures, strong light sources or direct sunlight.
- This product is not a toy. Keep out of reach of children.
- Dispose of batteries as chemical waste. Remove the batteries when you are not using the system for a longer period of time. Check the polarity (+/-) of the batteries when inserting them in the product. Wrong positioning can cause an explosion.
- Repairs or service should only be performed by qualified personnel.

Requirements

This product requires a Smart me Zigbee Gateway (sold separately) that is connected to the Internet. Follow the instructions for the Smart me Gateway to add it.

Installation of the Smart me app

Download and install the Marmitek Smart me app from the Apple app store or the Google Play store. Launch the Smart me app after installation is completed.



Installation of the Push LE

- Open the Push LE housing by sliding the front to the left and pull the plastic battery strip to activate the battery.
- The indicator light should start flashing rapidly. If the light does not blink, press push button 1 for 10 seconds until it starts to blink.
- Launch the Smart me app from your smart phone ortablet.
- Select the Smart me Zigbee Gateway.
- Click on the + (at the bottom of the screen) to add a new product, confirm that the indicator light is flashing quickly and follow the instructions.
- Press Help button during installation for more information or when installation fails.

Notes for using the product

- After the installation is completed you can configure the Push LE by using the app.
- Check our website <u>www.marmitek.com</u> for more details and how to use the Smart me products.

Technical specifications

Triggered action	One click, double click, long press 5s
Battery life	50.000 clicks – 2 years @ 30 per day
Wireless technology	Zigbee 3.0
Operating range	up to 30 meters in open area
Power	Battery CR2430
Standby current	20μΑ
Dimensions (h x w x d)	86 x 86 x 13 mm
IP code	20 (not dust proof, not waterproof)

Declaration of Conformity

Hereby, Marmitek BV, declares that the Push LE is in compliance with the essential requirements of the 2014/53/EU Directives.

Full Declaration of Conformity is available at www.marmitek.com/en/declarations-of-conformity/

More detailed user guide and instructions are available on our website at www.marmitek.com/en/declarations-of-conformity/



smart me

20752/20210623 | Push LE™ all rights reserved © MARMITEK stay connected marmitek.com

Documents / Resources



MARMITEK Push LE WHT/BLK Smart Zigbee Switch [pdf] User Guide

Push LE WHT BLK, Smart Zigbee Switch, Push LE WHT BLK Smart Zigbee Switch, Zigbee Switch, Switch, 08612, 08613

References

- Marmitek | Smart home and wireless HDMI & audio | since 1997
- Marmitek | Smart home and wireless HDMI & audio | since 1997
- M Declarations of Conformity | Marmitek