

MARMITEK Sense ME Zigbee Motion Sensor User Guide

Home » MARMITEK » MARMITEK Sense ME Zigbee Motion Sensor User Guide 🖺







Contents

- 1 Package content
- 2 Safety Instructions
- 3 Installation of the Smart me
- 4 Technical specifications
- 5 Documents / Resources
 - 5.1 References
- **6 Related Posts**

Package content

motion sensor
CR2450 battery
magnetic wall mount
3M adhesive tape
quick guide
This product requires a Zigbee gateway (sold separately).

Marmitek Smart me app



http://www.marmitek.com/media/qr/Smart me ug store aa 01.html

Multi language user guide



http://www.marmitek.com/media/qr/ple_ug_ma_aa_01.html

Safety Instructions

Please read these instructions thoroughly before you use the device and keep them for future reference. **Only for indoor use.**

- Do not expose the product to extremely high or low temperatures, strong light sources or direct sunlight.
- This product is not a toy. Keep out of reach of children.
- Dispose of batteries as chemical waste. Remove the batteries when you are not using the system for a longer period of time. Check the polarity (+/-) of the batteries when inserting them in the product. Wrong positioning can cause an explosion.
- Repairs or service should only be performed by qualified personnel.

Requirements

This product requires a Smart me Zigbee Gateway (sold separately) that is connected to the Internet.

Installation of the Smart me app

Download and install the Marmitek Smart me app from the Apple app store or the Google Play store. Launch the Smart me app after installation is completed.

Follow the instructions and register for a new account.

Installation of the Sense MA


- Open the housing of the Sense MA by unscrewing the top and pull the plastic battery strip to activate the battery.
- The indicator light should start flashing quickly. If the indicator light does not flash, press the reset button for 5 seconds until it starts flashing.
- Launch the Smart me app from your smart phone or tablet.
- Select the Smart me Zigbee Gateway.
- Click on the + (at the bottom of the screen) to add a new product, confirm that the indicator light is flashing quickly and follow the instructions.
- Press Help button during installation for more information or when installation fails.

Notes for using the product

- After the installation is completed you can configure the Sense MA by using the app.
- Check our website <u>www.marmitek.com</u> for more details and how to use the Smart me products.

Technical specifications

Туре	Water leakage & flooding
Detection water level	0.5mm
IP code	IP66 (water resistant)
Battery life	3 years
Wireless technology	Zigbee 3.0
Operating range	up to 30 meters
Power	Battery CR2032
Standby current	< 5μΑ
Dimensions (h x w x d)	46 x 46 x 14 mm



Declaration of Conformity

Hereby, Marmitek BV, declares that the Sense MA is in compliance with the essential requirements of the 2014/53/EU Directives.

Full Declaration of Conformity is available at www.marmitek.com/en/declarations-of-conformity/

More detailed user guide and instructions are available on our website at www.marmitek.com/



smart me

20752/20210623 | Push LE™ all rights reserved © MARMITEK stay connected marmitek.com

Documents / Resources



MARMITEK Sense ME Zigbee Motion Sensor [pdf] User Guide

Sense ME, Zigbee Motion Sensor, Sense ME Zigbee Motion Sensor, Motion Sensor, Sensor, 08616

References

- Marmitek | Smart home and wireless HDMI & audio | since 1997
- Marmitek | Smart home and wireless HDMI & audio | since 1997
- M Declarations of Conformity | Marmitek

Manuals+,