




MARQUANT 003344 Alarm Clock Instruction Manual

[Home](#) » [MARQUANT](#) » MARQUANT 003344 Alarm Clock Instruction Manual 

Contents

- [1 MARQUANT 003344 Alarm Clock](#)
- [2 OPERATING INSTRUCTIONS](#)
- [3 TECHNICAL DATA](#)
- [4 DESCRIPTION](#)
- [5 USE](#)
- [6 SETTINGS](#)
- [7 ALARM](#)
- [8 SWITCHING FROM °C TO °F](#)
- [9 BACKLIGHT](#)
- [10 SWITCH FOR LIGHT SENSOR](#)
- [11 Documents / Resources](#)
- [12 Related Posts](#)

MARQUANT®

MARQUANT 003344 Alarm Clock



OPERATING INSTRUCTIONS

Important! Read the user instructions carefully before use. Save them for future reference. (Translation of the original instructions).

TECHNICAL DATA

Battery: 2 x1.5 V AAA

DESCRIPTION



- 1. Snooze
- 2. Time
- 3. Button SNOOZE/LIGHT

4. Light sensor
5. Time to set off alarm
6. Date (month/day)
7. Temperature
8. Switch for light sensor
9. Alarm selector
 - WORK AL. ON
 - AL. ON
 - AL. OFF
10. Button 12/24/YEAR
11. Button TEMP/MIN/DATE
12. Button HOUR/MONTH
13. Selector (4 modes)
 - LOCK
 - TIME SET
 - DATE SET
 - AL.SET
14. Battery cover

USE

REPLACING THE BATTERY

1. Open the battery cover by pushing it down.
2. Remove the old battery by pulling the black band.
3. Insert new 1.5 V AAA batteries with the correct polarity as shown by the markings in the battery compartment.
The black band should lie under the first battery to simply taking it out.
4. When the batteries are inserted a short audio prompt will be heard and all the symbols are shown on the display. The display then shows 12:00 AM.
5. Replace the cover.

SETTINGS

1. The long line on the selector shows the selected function.
2. Press the button for at least 3 seconds to increase/reduce the setting.
3. Put the selector in LOCK mode to confirm the settings.

Time

1. Put the selector in TIME SET mode. The digits for the time flash.
2. Set the hour with the HOUR/MONTH button. Set the minutes with the TEMP/MIN/DATE button.

12/24 hour display

1. Put the selector in LOCK mode.
2. Push the 12/24/YEAR button to select 12/24 hour display.

Date

1. Put the selector in DATE SET mode. The digits for year and date start flashing.
2. Set the year with the button 12/24/YEAR.
3. Set the date with the TEMP/MIN/DATE button.
4. Set the month with the HOUR/MONTH button.

ALARM

NOTE:

- For the first 10 seconds the alarm is 1 audio prompt per second.
- If the alarm is not switched off within 10 seconds it switches to 2 audio prompts per second for the next 10 seconds.
- If the alarm is not switched off within 20 seconds it continues with 2 audio prompts per second for the next 10 seconds and then 4 audio prompts per second.

Setting the alarm

1. Put the selector for alarm on/off in AL. SET mode. The alarm time starts flashing.
2. Set the hour with the HOUR/MONTH button. Set the minutes with the TEMP/MIN/DATE button.
3. Put the selector for alarm on/off in LOCK mode to confirm the settings.

Enable/disable the alarm

1. Enable the alarm function by moving the selector for alarm on/off to one of the following modes:
 - AL.ON
The alarm is enabled for each weekday and MO-SU is shown in the display.
 - WORKAL.ON
The alarm is only enabled for Monday to Friday and MO-FR is shown in the display.
2. Disable the alarm function by moving the selector for alarm on/off to AL.OFF mode

Snooze button

When the alarm goes off press the snooze button to switch off the alarm for the next 5 minutes.

Switching off the alarm

To switch off the alarm press any button except SNOOZE/ LIGHT.

SWITCHING FROM °C TO °F

1. To switch the temperature unit put the selector in LOCK mode.
2. Press the TEMP/MIN/DATE button to change the temperature unit.



BACKLIGHT

- The backlight goes on when the SNOOZE/LIGHT button is pressed.
- The backlight stays on for 5 seconds.

SWITCH FOR LIGHT SENSOR

- Put the switch for the light sensor in ON mode to enable the backlight on the display in poor light.
- Put the switch for the light sensor in OFF mode to disable the backlight on the display in poor light.

Documents / Resources

	<p>MARQUANT 003344 Alarm Clock [pdf] Instruction Manual 003344, Alarm Clock</p>
	<p>MARQUANT 003344 Alarm Clock [pdf] Instruction Manual 003344, Alarm Clock</p>