

# MARVO KG946 Custom Keycap Keyboard User Manual

Home » MARVO » MARVO KG946 Custom Keycap Keyboard User Manual



KG946 Custom Keycap Keyboard User Manual



#### **Contents**

- 1 KG946 Custom Keycap
- **Keyboard**
- 2 Features
- 3 Safety Notes
- 4 Installation
- 5 Use
- **6 Troubleshooting**
- **7 Warranty Conditions**
- **8 EU Declaration of Conformity**
- 9 Documents / Resources
  - 9.1 References
- 10 Related Posts

# KG946 Custom Keycap Keyboard

#### Dear customer,

Thank you for purchasing our product. Please read the following instructions carefully before first use and keep this user manual for future reference. Pay particular attention to the safety instructions. If you have any questions or comments about the device, please contact the customer line.

**<u>www.alza.co.uk/kontakt</u>** 

© +44 (0)203 514 4411

Importer Alza.cz a.s., Jankovcova 1522/53, Holešovice, 170 00 Prague 7, www.alza.cz

## **Features**

- Full anti-ghosting support.
- Dedicated multimedia controls including volume roller.
- 21 selectable lighting schemes.
- · Backlit characters, perfect for playing in low light.

Keys	87
Switch type	Mechanical (Red)
Switch rating	50 million presses
Key route	4.0 ± 0.5 mm
Operating forc	50 ± 10 g
Backlight	5 mixed colors
Interface	USB 2.0
Cable length	1.6 m
Size	358 x 130 x 40 mm

#### Wrist pad Specifications

**Size:** 357 x 72 x 19 mm

### **System Requirements**

PC system or compatible with one USB port available; Windows 7 or newer operating system.














- · No-driver Needed
- 50 million Switch Rating
- · Multimedia Functions
- · Full Anti-Ghosting
- · Ergo Design
- 100 % Pure Performance

# **Safety Notes**

- Keep the equipment dry. Keep away from precipitation, humidity, all types of liquids and condensation.
- Do not use the product with wet hands.
- Do not use or store the equipment in dusty or dirty areas.
- Do not store the equipment under high-temperature or low-temperature conditions (this may damage it).
- Do not drop, knock, or shake the equipment (use may result in breakage).

## Installation

1. Connect the keyboard to an available USB port on your computer. If the keyboard is used for the first time wait approx. 15 seconds to install the generic **driver**.



**NOTE:** The keyboard does not have a specialized driver and does not require one for proper operation and functionality.

## Use

The keyboard configuration and using the special functions are done by using the various key combinations detailed below..

Multimedia and office functions

FN + F1: stop	FN + F7: email
FN + F2: previous song	FN + F8: calculator
FN + F3: play/pause	FN + F9: music
FN + F4: next song	FN + F10: decrease audio volume
FN + F5: open my computer	FN + F11: increase audio volume
FN + F6: internet	FN + F12: mute

## Back light control and customization

Press FN + INS/DEL/HOME/PGUP/END to change the backlight mode.

Press FN  $+\uparrow/\downarrow$  to change the brightness.

Press FN +  $\leftarrow$ / $\rightarrow$  to change the backlight speed.

Press FN + =/+ to switch to right direction.

Press FN + -/ to switch to left direction.

Press FN + 1/2/3 to change customization modes. Press FN +

ESC to customize kyes and press again to save.

Press FN + 4/5/6/7 to switch to pre-set fixed lighting modes.

Press FN + ESC + F1 + F3 + F5 to restore to factory settings in order.

#### Other functions

FN+ESC: art/Save backlight recording



: custom backlight recording slots (CM1-CM3)

Press Fn+1 to choose CM1-slot then press FN+ESC to start backlight recording.

Then choose the keys you want have lit. Press FN+ESC again to stop and save your recording. All the custom slots (CM1CM3) operate in the same way.

While in recording mode any other keyboard function will not word at this time.

Caps Lock, Scroll Lock, Num Lock and WIN-keys are not record able.

FN + WIN Lock. Press to lock Win-key. Press again to unlock

# **Troubleshooting**

In case of incorrect operation follow the steps below:

- Check the integrity of the connectors.
- · Check the connection to the computer.
- · Check your computer settings.
- Disconnect and reconnect the equipment; restart the computer.

If the problem persists, please contact your local seller.

# **Warranty Conditions**

A new product purchased in the <u>Alza.cz</u> sales network is guaranteed for 2 years. If you need repair or other services during the warranty period, contact the product seller directly, you must provide the original proof of purchase with the date of purchase.

The following are considered to be a conflict with the warranty conditions, for which the claimed claim may not be recognized:

- Using the product for any purpose other than that for which the product is intended or failing to follow the instructions for maintenance, operation, and service of the product.
- Damage to the product by a natural disaster, the intervention of an unauthorized person or mechanically through the fault of the buyer (e.g., during transport, cleaning by inappropriate means, etc.).
- Natural wear and ageing of consumables or components during use (such as batteries, etc.).
- Exposure to adverse external influences, such as sunlight and other radiation or electromagnetic fields, fluid
  intrusion, object intrusion, mains over voltage, electrostatic discharge voltage (including lightning), faulty supply
  or input voltage and inappropriate polarity of this voltage, chemical processes such as used power supplies,
  etc.
- If anyone has made modifications, modifications, alterations to the design or adaptation to change or extend the functions of the product compared to the purchased design or use of non-original components.

## **EU Declaration of Conformity**

This product complies with the essential requirements of Directives 2014/30/EU and 2011/65/EU including amendments 2015/863/EU.

#### **WEEE**

This product must not be disposed of as normal household waste in accordance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE – 2012/19/ EU). Instead, it shall be returned to the place of purchase or handed over to a public collection point for the recyclable waste. By ensuring this product is disposed of correctly, you will help prevent potential negative consequences for the environment and human health, which could otherwise be caused by inappropriate waste handling of this product. Contact your local authority or the nearest collection point for further details. Improper disposal of this type of waste may result in fines in accordance with national regulations.





## **Documents / Resources**



MARVO KG946 Custom Keycap Keyboard [pdf] User Manual KG946 Custom Keycap Keyboard, KG946, Custom Keycap Keyboard, Keyboard

#### References

- Series et al.
- alza.co.uk
- <u>® alza.de</u>

- 🍇 alza.hu
- 🍇 alza.sk

Manuals+,