



## Master Lock X055ML Lock X Line Security Safe Owner's Manual

[Home](#) » [Master Lock](#) » Master Lock X055ML Lock X Line Security Safe Owner's Manual 

Master Lock X055ML Lock X Line Security  
Safe Owner's Manual



Security Safe Owner's Manual



## Contents

- [1 Security Safe](#)
- [2 For Key Lock Safes](#)
- [3 For Digital Combination Safes](#)
- [4 Using Your Security Safe](#)
- [5 Bolt-Down Instructions](#)
- [6 Troubleshooting](#)
- [7 Documents / Resources](#)
  - [7.1 References](#)
- [8 Related Posts](#)

## Security Safe

Thank you for choosing your security safe to store all important documents and valuables.

We hope that this product will help you stay organized and provide you with the peace-of-mind of knowing the things most important to you are protected.

## For Key Lock Safes

Your product is equipped with a high security key lock.  
Two (2) keys are provided.

## For Digital Combination Safes

Opening Your Safe for the First Time (Using the Override Key)



1. Remove the cover located between the knob and keypad.
2. Insert the override key provided and turn counterclockwise.
3. Turn the knob clockwise to open the door.
4. Turn key back clockwise to remove the key and replace the cover on the door.

**Note:** In an emergency, situation the safe can be opened using your override key. **DO NOT store your override key inside the safe.**

## Installing the Batteries

1. With the door open, remove the battery compartment cover located on the inside of the door by sliding the cover in the direction of the arrow.
2. Install four (4) AA size alkaline batteries.

**Note:** Follow the polarity (+/-) markings in the battery compartment to ensure proper installation.

3. Slide the battery cover back into place.



**Note:** Do not use rechargeable batteries or any other type of non-alkaline battery. Do not mix old and new batteries. Do not mix alkaline and other battery types.

## Using Your Security Safe

**IMPORTANT:** All security safe models initially work using the factory code 1-7-5-0-0-#. It is highly recommended and important to the security of your valuables that you re-program the safe with a new user code. Once reprogrammed the factory code can no longer be used to open your safe.

### Programming Your New User Code



1. Open the safe's door and remove the battery compartment cover.
2. Locate the button inside the battery compartment and press.  
The yellow LED light will go on.
3. Enter a new user code (between 2-8 digits) followed by the “#” key. The yellow LED light will go off to indicate the new code has been accepted and stored.
4. Replace the battery compartment cover.

**Note:** Always test a new code before storing any valuables inside the safe.

### Unlocking Your Safe

1. Enter your factory code or user code followed by #.
2. The green LED light will go and remain on for 5 seconds.
3. Within 5 seconds, turn the knob clockwise and pull open the door.

### Locking Your Safe

1. With the bolts retracted into the door, firmly close the door of the safe.
2. Turn the knob in the counter-clockwise direction to secure your safe.

## Bolt-Down Instructions

To help provide maximum security, it is highly recommended that you bolt down your safe.

1. Set the safe in the place you intend to bolt it down and open the door.
2. Using a pencil mark the floor through the holes provided in the bottom or back of your safe.
3. Move the safe away and drill holes of the appropriate diameter and depth for the type of hardware being used and the mounting surface.
4. Place the safe back over the holes and install the fasteners as required.

**Note:** It is not recommended to attempt to bolt your safe to both the floor and wall. If bolting to a wall, please ensure the safe is resting on a supporting surface such as a table or shelf.

## Troubleshooting

THE PROBLEM:	WHY IT IS HAPPENING:	THE SOLUTION:
A red LED light goes on when a button is pressed.	Battery power is low.	<ul style="list-style-type: none"><li>• Install four (4) new AA size alkaline batteries.</li><li>• Open with override key.</li></ul>
Digital lock is unresponsive when attempting to press in code.	Battery power is low.	<ul style="list-style-type: none"><li>• Install four (4) new AA size alkaline batteries.</li><li>• Open with override key.</li></ul>
5 beeps and a yellow LED light after entering your code.	Invalid code.	<ul style="list-style-type: none"><li>• Wait one minute and retry your code.</li><li>• Open with override key.</li></ul>



Figure 1

WEEE Figure 1: In the European Union (EU), this symbol means that electrical and electronic equipment should not be disposed of with general household waste. Please contact your dealer, supplier or local recycling authority for further details regarding appropriate disposal of this product and your nearest designated collection facility.

 **SentrySafe®**

**Master  
Lock®**



: [sentrysafe.com](https://sentrysafe.com)  
: [masterlock.eu](https://masterlock.eu)


**[SENTRYSAFE.COM](http://SENTRYSAFE.COM)**

Master Lock Company LLC, Milwaukee, WI  
53210 U.S.A. | 800-308-9244  
Master Lock Canada, Mississauga, Ontario  
L6H 5S7 Canada | 800-227-9599  
© 2022 Master Lock Company | All Rights Reserved  
7000-0885

**SentrySafe**

Customer Service: 1-800-828-1438  
Mexico Customer Service: 01-800-451-0821

**Documents / Resources**

	<p><b><a href="#">Master Lock X055ML Lock X Line Security Safe</a></b> [pdf] Owner's Manual X055ML Lock X Line Security Safe, X055ML, Lock X Line Security Safe, Security Safe</p>
---	--

**References**

-  [Locks, Padlocks and Security Products | Master Lock](#)