



MATRIX CLIX Keyboard User Manual

[Home](#) » [MATRIX](#) » MATRIX CLIX Keyboard User Manual

MATRIX CLIX Keyboard



Contents [[hide](#)]

[1 BASIC KEYBOARD FUNCTIONS](#)

[2 FUNCTIONS AND DUNCTION LOCK](#)

[3 COMMANDS AND COMMADN LOCK](#)

[4 RGB FUNCTIONS](#)

[5 ARROW KEYS](#)

[6 MISCELLEAOUS FUNCTIONS](#)

[7 Documents / Resources](#)

[8 Related Posts](#)



BASIC KEYBOARD FUNCTIONS

♦ C – COPY	♦ P- PRINT	♦ [– DECIREASE FONT SIZE
♦ X – CUT	♦ A – SELECT ALL	♦] – INCREASE FONT SIZE
♦ V – PASTE	♦ F- FIND	♦ SCROLL WHEEL – INC. OR DEC, FONT
♦ Z-UNDO	♦ O – OPEN	♦ HOLD CTRL + CORRESPONFING KEY
♦ Y-REDO	♦ S – SAVE	
♦ R- REFRESH	♦ N – NEW	
♦ ALT+ F'N + M – CTRL +ALT+ DELETE		
♦ BACKSPACE – DELETES PIREV. WORD		



FUNCTIONS AND DUNCTION LOCK

PRESS FN + CORRESPONDING KEY FN + E FOR COMMAND ONLY LOCK REPEAT TO TURN OFF OR FN + Q

◆ 1 – F1	◆ 2-F2
◆ 3- F3	◆ 4-F4
◆ 5 – F5	◆ F – F6
◆ 7 – F7	◆ 8 -F8
◆ 9 – F9	◆ 0- F10
◆ -(MINUS) – f 11	◆ = – F12
◆ / – ?	◆ ALT-/
◆ MENU – RIGHT' CLICK	



COMMANDS AND COMMADN LOCK

PRESS FN + R CORRESPONDING KEY FN + R FOR CQ,MMAND ONLY LOCK REPEAT TO TURN OFF Q,R FN + Q

◆ U – PRINT SCREEN	◆ K-HOME
◆ I – SCROLL LOCK	◆ L-PAGE UP
◆ J – INSERT	◆ M- DELETE
◆ .- PAGE DOWN	◆ , – END
◆ O – PAUSE/BREAK	



M RGB FUNCTIONS

PRESS FN +] FOR LIGHT CV1 CLE

* IND1 ICATES CYCLE LIGHT FUNCTION

PRESS FN + B,ACKSPACE TO TURN OFF

◆ SINGLE KEY*
◆ PRESSED KEY ROW*
◆ SOUND, VISUALIZER*
◆ RIPPLE FROM PRESSED KEY*
◆ V N + [– BRIGHTNESS UP
◆ FN + P – BRIGHTNESS DOWN
◆ FN + ; ~ LIGHT SPEED SLOWS
◆ FN + ‘ – – LIGHT SPEED FASTER



◆ SOLID COLOR*
◆ FULL KEYBOARD CHANGES COLOR*
◆ WAVE FROM RIGHT GHT TO LEFT”
◆ SPIN FROM, CENTER*
◆ WAVE FROM BOTTOM TO TOP’
◆ FN + [– BRIGHTNESS UP’
◆ FN + P – BRIGHTNESS DOWN
◆ FN + ; ... LIGHT SPEED SLOWS
◆ FN + ‘ .. LIGHT SPEED FASTER



PRES FN + CORRESPONDING KEY FN + W FOR ARROW ONLY LOCK REPEAT TO TURN OFF OR FN + Q

◆ / – UP ARROW

◆ ALT – LEFT ARPOW

◆ MENU – DOWN ARROW

◆ VCTR; – RIGHT ARROW



MISCELLEAOUS FUNCTIONS

PRESS FN + THE CORRESPONDING KEY FN + W FOR ARROW ONLY LOCK REPEAT TO TURN OFF Q,R FN + Q

◆ WIN KEV – DISABLES WIN KEY

◆ ESC – GRAVE ACCENT (')

◆ SHIFT + ESC .. TILDE (–)





MATRIX KEYBOARDS

Documents / Resources



[MATRIX CLIX Keyboard](#) [pdf] User Manual
CLIX Keyboard