Home » Mau » Mau IVY3 3 Cat Tree Instruction Manual

Mau IVY3 3 Cat Tree Instruction Manual


Mau

Contents

- 1 IVY 3
 - 1.1 Assembly Instructions
- 2 Documents / Resources
 - 2.1 References

IVY 3


Assembly Instructions



Scan the OR code to view the assembly video or go to maupets.com/pages/assembly



Label	Shape	Description	Quantity
А		Lower branch	1
В		Upper branch	1
С		Tool	1
D	-:-	Base	1
E		Basket	3
F		Cushion	3
G		Fluffy disc	1
Н	(D 10x25mm bolt	3
I		D 10x80mm bolt	4
J	(e-moxacem)	Double-sided screw	1
К	0	Small washer	4



USE TOOL (C) TO ASSEMBLE

QUESTIONS?


Contact support at info@maupets.com

STEP 1-A

Align the **lower branch (A)** with the 4 holes on the **base (D)**. Ensure the logo is facing forward, and the first arm is facing left.

STEP 1-B


Put the **bolt (I)** through the **small washers (M)** and insert them from the bottom of the base. Tighten the screws into the lower branch using the included **tool (C)**.



- 1. LOWER BRANCH (A)
- 2. BASE (D)

STEP 2-A

Screw the double-sided screw (J) into the top of the lower branch and then place the fluffy disc (G) on top of it.




- 1. FLUFFY DISC (G)
- 2. DOUBLE- SIDED SCREW(J)

STEP 2-B

May require two people


Grab the **upper branch (B)** and screw/twist it into the **lower branch (A)**. Try to keep the branch as staight as possible.



- 1. UPPER BRANCH (B)
- 2. FLUFFY DISC (G)
- 3. LOWER BRANCH (A)

STEP 3

Use the **screws (H)** to attach the baskets onto the arms and use the **tool (C)** to tighten them. Place the **cushions (F)** inside of the baskets.



A1: Tighten the screws with tool (C).

- 1. CUSHION (F)
- 2. TOOL (C)
- 3. BASKET (E)

Documents / Resources



Mau IVY3 3 Cat Tree [pdf] Instruction Manual IVY3, IVY3 3 Cat Tree, 3 Cat Tree, Tree

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.