

Maxblue MB-C02 Coffee Filter User Manual

Home » Maxblue » Maxblue MB-C02 Coffee Filter User Manual



Maxblue MB-C02 Coffee Filter User Manual



Contents

- 1 Installation instructions
- 2 Important
- 3 Cartridge preparation
- 4 Install the cartridge
- 5 Rinsing and preparation
- 6 Care & maintenance
- 7 Documents / Resources
 - 7.1 References
- **8 Related Posts**

Installation instructions

Coffee filter replacement for Brita® Intenza+

Important

The filter was created to become a premium quality alternative for customers who are seeking for a replacement cartridge to be used with coffee makers and other devices employing the Brita Intenza+ filtering system.

To install, simply follow the steps required with the original cartridge; the only difference is that the "aroma adjustment" has been omitted – blending and flow correspond to average usage and consumption and have been embedded in the design.

Cartridge preparation


Clean your hands carefully before touching the filter. Pull out the cartridge from the plastic wrapper. This enclosure can be recycled along with most other recyclable plastics.

Fill a clean bowl with fresh cold water, sink the cartridge under the surface and shake it so that \any trapped air inside it is released.



Install the cartridge

Without removing the water reservoir from the machine, pull out the cap and push the cartridge tightly inside the receiver, until you sense it click-locking in place. Make sure it is sitting firmly and it can't move freely; otherwise, you will experience poor performance




Rinsing and preparation

Dislodge the water reservoir from the coffee maker.*

Fill the reservoir with fresh, cold water Re-install the water reservoir into the coffee maker.*

Flush the filter. If your model supports the cartridge change/flush function, you can use it now. Otherwise, channel the first full reservoir of water through the filter as "hot water only", without adding coffee.

*Read the manufacturer's manual when needed.



Care & maintenance

Regularly check the water reservoir to make sure that the cartridge is firmly in place and the filtering process is working seamlessly. Cartridge replacement should take place after 100L of use. If the coffee machine remains unused for more than 15 days, for example while you are out on vacation, it is recommended to change the filter before using it again.

Warning: Always remove cartridge prior to descaling the machine

Qingdao Ecopure Filter Co., Ltd.



Tel: 1-888-352-3558 (U.S.)

E-mail: service@maxbluefilter.com
Add.: No.13, Yishengbai Road Jimo, Qingdao, China



Documents / Resources



Maxblue MB-C02 Coffee Filter [pdf] User Manual MB-C02 Coffee Filter, MB-C02, Coffee Filter, Filter

References

• User Manual

Manuals+, Privacy Policy