

maxpower MPD158XB Bluetooth Speaker User Manual

Home » maxpower » maxpower MPD158XB Bluetooth Speaker User Manual

Contents

- 1 maxpower MPD158XB Bluetooth
- Speaker
- **2 IMPORTANT SAFETY MEASURES**
- **3 PRODUCT FEATURES**
- **4 REMOTE CONTROL**
- **5 CONNECTING**
- **6 PANEL FUNCTION INSTRUCTIONS**
- 7 FCC STATEMENT
- 8 Documents / Resources
 - 8.1 References



maxpower MPD158XB Bluetooth Speaker



IMPORTANT SAFETY MEASURES

Before using this machine, please read all the safety and operating instructions. Meanwhile, please observe all the indications about safe operating. These safety and operating instructions should be kept in condition of consultation.










- 1. Protection of electric power supply line: Be aware that the electric power supply line is not tramped, pressed by heavy objects. Pay special attention to the plug of the power supply line and outlet on the machine. DO NOT lengthen the electric shock, and DO NOT pull or drag the power supply line.
- 2. Ventilation: This set must be put in a ventilated place. DO NOT put the disk on it or cloth to cover it. The distance away from the wall should not be less than 10 centimeters. DO NOT put this set on the bed, sofa, carpet, or other objects with similar surfaces in case of good ventilation.
- 3. Casing Dismantling: DO NOT dismantle the casing. If one touches the inner components, he will probably get a serious electric shock.
- 4. Unusual smell: When you discover an unusual smell and smoke, cut power supplies immediately and pull out the plug from the outlet on the wall. Contact the shop or the nearest repair center.

Attention: This set applies to AC 110V / 50Hz~60Hz power supply. Use a standard power supply. Please be sure of the correct power supply before using it.

PRODUCT FEATURES

- Wireless
- Plays songs stored in an external audio device.
- · Guitar input
- · Microphone inputs
- · Wireless microphone included
- · With remote control
- Built-in rechargeable battery Super dynamic sound speaker
- · X-Bass is powerful

REMOTE CONTROL



- Standby
- LINE (Audio input)
- Prev/FM CH-
- Play/pause/FM tuner
- Next/FM CH+
- Repeat
- Stop
- Volume up
- Volume down
- Mute
- Wireless disconnect
- ¹⁻⁹ Number

CONNECTING

- 1. This set applies to AC 110V, 50/60Hz
- 2. AC power: The battery can be charged when connected to AC power.
 - The red light on the battery is charging, it will change to green once bat.

- Tery complete charge.
- 3. The internal battery will be charged even device is switched off when plugged into AC power.
- 4. Speaker battery can be charged using a 12V external car battery as well(connect cable not included) by "DC 12V input". Please make sure "+" and "-" are the right connections.
- 5. Adjust function keys to your personal audio preference.

BATTERY & CHARGING


- 1. The unit takes approximately 8 hours tocharge fully. Itt will automatically begin charging once the power cord is connected.
- 2. If the battery power is low may cause sound distortion or stop play. Please charge the battery on time.
- 3. To maximize the battery's lifespan, please charge the battery immediately. When the unit is not used for prolonged periods, the battery will gradually lose its power. It is recommended to fully charge the battery at least every 30 days.
- 4. Tsaveng battery, please power off once you stop using it.

HOW TO CONNECT TO BT:


When you turn on the speaker, the display will read OPEN, which means your speaker is ready to connect. Go to your smart device and search for your BT device. You will see the device name MPD158, X and, B, and please select that. Please select MPD15,8,,X B and you will be connected.

For the TWS CONNECTION -HOW TO PAIR TWO SPEAKERS

For the first, bring two speakers next to each other, turn on both the speakeDisplayslays should read For theen. For the first speaker/primary speaker, please press and hold the TWS button for 3 seconds. The primary speaker will sound an alarm, and the display will show "BTS, , T" and the seconspeaker will r automatically connect to the primary speaker. The display of the secondary speaker will say BT. Now you may connect to BT from your smart device and listen to music from both your speakers.



PANEL FUNCTION INSTRUCTIONS



1. MIC.VOL: MICROPHONE VOLUME ADJUST


- 2. M. TREBLE MICROPHONE TREBLE ADJUST
 - M.BASS MICROPHONE BASS ADJUST
 - ECHO ECHO ADJUST
 - DELAY DELAY ADJUST
- 3. VOLUME MASTER VOLUME ADJUST
- 4. REC: RECORDIN; INSERT CARD PRESS THIS BUTTON FOR RECORDING, PRESS AGAIN TO STOP AND PLAY RECORDING SOUND REPEAT
- 5. X-BASS ADJUST
- 6. AUDIO INPUT
 - MIC PRI: MICROPHONE PRIORITY ON/OFF SWITCH
 - GT IN: GUITAR INPUT JACK
 - MIC: MICROPHONE INPUT JACK
- 7. EQUALIZER
- 8. POWER: ON/OFF SWITCH
- 9. DISPLAY SCREEN
- 10. CARD SLOT
- 11. GT. VOL: GUITAR VOLUME ADJUST
- 12. LED MODE ADJUSTMENT
 - DISC DISCONNECTED
- 13. MODE: MODE SELECT

TWS/SCAN: PLAY/PAUSE/TWS/FM STATION AUTOMATIC SEARCH

PREV: PREVIOUS SONG

NEXT: NEXT SONG

POWER INPUT(AC 110V-240V)



FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and usedbyh the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution

Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interterence, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Documents / Resources



maxpower MPD158XB Bluetooth Speaker [pdf] User Manual MPD158XB, MPD158XB Bluetooth Speaker, Bluetooth Speaker, Speaker

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.