

MaxTo MX1 Helmet Bluetooth Intercom Headset



MaxTo MX1 Helmet Bluetooth Intercom Headset User Manual

[Home](#) » [MaxTo](#) » MaxTo MX1 Helmet Bluetooth Intercom Headset User Manual 

Contents

- [1 MaxTo MX1 Helmet Bluetooth Intercom Headset](#)
- [2 Product Usage Instructions](#)
- [3 FAQ](#)
- [4 Packing List](#)
- [5 Function Introduction](#)
- [6 Speaker installation](#)
- [7 Fixed MX1 by Glue Clamp](#)
- [8 Product Introduction](#)
- [9 Specifications](#)
- [10 Warranty Service](#)
- [11 FCC STATEMENT](#)
- [12 Documents / Resources](#)
 - [12.1 References](#)



MaxTo MX1 Helmet Bluetooth Intercom Headset



Product Usage Instructions

1. Unbox the device and ensure all components are included.
2. Connect the power adapter to the device and plug it into a power source.
3. Power on the device and follow the on-screen instructions for initial setup.

Operating the Device

1. Familiarize yourself with the device controls and interface.
2. Use the menu options to navigate through different functions.
3. Refer to the user manual for specific features and functionalities.


Troubleshooting

- If you encounter any issues, refer to the troubleshooting section of the user manual or contact customer support for assistance.


FAQ

- **Q:** What should I do if the device stops responding?
- **A:** Try restarting the device by powering it off and on again. If the issue persists, contact customer support for further assistance.
- **Q:** How do I change the language settings?
- **A:** Navigate to the settings menu, select language preferences, and choose the desired language from the list of options.


Packing List



Bluetooth Device



Microphone & Ear Speakers




Clamp



Velcro Clamp



Headphone Velcro



USB Cable




Screw Driver



Manual

Function Introduction



Operating range
800 meters




Connected with
2 mobile phones



Stereo music
A2DP



Voice Dial



Prompt voice
switch



Playback
Control




Water-proof




Advanced
noise control

Speaker installation

1. Open the inner lining on the ear position of the helmet and attach the VELCRO loop.



2. Attach the headphone Velcro hook to the loop (the short-line speaker is on the left).




3. Place the butterfly sticker in the right position on the left side of the helmet, match the microphone with the mouth position, and tidy up the line and lining.




Fixed MX1 by clamp


1. Loosen the screws on the back of the clamp with the provided screwdriver.



2. Open the lining of the helmet, insert the clamp in the proper position on the left of the helmet and fasten the screw.



3. Slide the backtrack of the device into the clamping track.




4. Insert the plug into the headset socket and the installation is complete.




Fixed MX1 by Glue Clamp

1. Slide the backtrack of the device into the clamping track.



2. Tear off the white paper on the back of the clamp and stick it in the right position on the left side of the helmet.




Diassembly of The Device



1. Pull out the headset plug.



2. Press the upper clamp buckle and move the device upward to remove it.



Product Introduction



Priority of Functions

- Level 1 Phone call
- Level 2 Bluetooth Intercom
- Level 3 Music

Specifications

- **Operating range:** Up to 800 meters
- **Standby time:** Up to 200 hours
- **Operating time:** Up to 20 hours
- **Charging time:** Approximately 2 hours
- **Charging interface:** Type-C Universal Plug
- **Battery Type:** Rechargeable Li-Polymer Batteries
- **Power Supply:** 5V $\overline{\text{---}}$ 0.5A
- **Operating Temperature:** 14F~131F (-10°C~55°C)
- **Storage temperature:** -4F~140F (-20°C~60°C)

Depending on the phone type and usage, the actual time may vary.

The working distance will be deviated due to the influence of environment and climate.

Matters Needing Attention

1. The appropriate storage temperature for this device is between -20°C and 60°C. Please do not store it in an environment with too high or too low temperatures. Otherwise, the service life will be affected.
2. Please do not expose it to open fire, to avoid explosion.
3. For a long period without being used, please keep the device in a dry place and charge it regularly (once every 3 months), to ensure it works properly.
4. When the bluetooth cannot be turned on, please plug in the power to reset.

Warranty Service

- MX1 warranty is 1 year
- The warranty period of the original battery is 6 months, and the warranty period of the original earphone is 6 months.
- Change card to a product warranty certificate, please keep it properly.
- Please attach a copy of the receipt on the warranty card to certify the purchase date.



- Date of purchase:.....
- Customer name:.....
- Customer phone:.....
- Customer address:.....

Please fill in the product failure description so that we can handle it for you in time.



FCC STATEMENT

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. this device may not cause harmful interference, and
2. this device must accept any interference received, including interference that may cause undesired operation.


Note: This equipment has been tested and found to comply with the limits for a Class B digital device, according to Part 15 of the FCC Rules.

These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used under the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Documents / Resources

	<p>MaxTo MX1 Helmet Bluetooth Intercom Headset [pdf] User Manual</p> <p>2ATZP-MAXTO-MX1, 2ATZPMAXTOMX1, MX1 Helmet Bluetooth Intercom Headset, MX1, MX1 Intercom Headset, Helmet Bluetooth Intercom Headset, Bluetooth Intercom Headset, Intercom Headset, Headset</p>
---	--

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.