


MAXUS P026 Shipping Scale



MAXUS P026 Shipping Scale User Manual

[Home](#) » [MAXUS](#) » MAXUS P026 Shipping Scale User Manual 

Contents

- 1 MAXUS P026 Shipping Scale
- 2 Product Information
- 3 Introduction
- 4 Safety Instructions
- 5 What's in the box
- 6 Description
- 7 General Operation
- 8 Documents / Resources
 - 8.1 References



MAXUS P026 Shipping Scale



Product Information

Specifications

- Weighing platform
- On-off button
- Mode button
- Hold button
- Tare button

FAQ

- **Q:** What should I do if the device was damaged in transit?
 - **A:** Do not install or use it and contact your dealer.

Introduction

To all residents of the United States

Important environmental information about this product



■ This symbol on the device or the package indicates that disposal of the device after its lifecycle could harm the environment. Do not dispose of the unit (or batteries) as unsorted municipal waste; it should be taken to a

specialized company for recycling.

This device should be returned to your distributor or to a local recycling service. Respect the local environmental rules.

If in doubt, contact your local waste disposal authorities.

Thank you for choosing!

Please read the manual thoroughly before bringing this device into service. If the device was damaged in transit, do not install or use it and contact your dealer.

Safety Instructions


Read and understand this manual and all safety signs before using this appliance.

- This device can be used by children aged from 8 years and above, and persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning the use of the device in a safe way and understand the hazards involved. Children shall not play with the device. Cleaning and user maintenance shall not be made by children without supervision.
- Protect this device from heat sources such as radiators, heat registers, stoves, or other appliances (including amplifiers) that produce heat.
- Do not remove the cover under any conditions. There are no user-serviceable parts inside. Never operate this device when its cover is removed.
- Familiarise yourself with the functions of the device before actually using it.

What's in the box




Digital postal scale




Drill Positioning Paper



User Manual



Two AAA Batteries



Type-c usb

Description

Refer to the illustrations of this manual.



1	weighing platform
2	on-off button
3	mode button

4	hold button
5	tare button

General Operation

Functional Instruction

1. Put the postal scale on a horizontal surface, and press ON/OFF to turn it on/off.
2. Press the MODE button to choose the weighing unit when the number on the screen shows zero clearing.
3. Put the stuff on the postal scale and wait till the reading become stable.

Tare Functional

1. Setting the weighing mode by following the above instruction.
2. Put the tare item on the scale, then press the TARE button and wait till the screen shows zero clearing.

On Hold Reading

Press the HOLD button while weighing to turn on the On Hold Reading mode

1. When the machine starts to zero, put the item to be weighed first. After the reading becomes stable, press the "HOLD" button. The display screen will display the character "HOLD", and the reading will remain unchanged when the weighing object is removed or added.
2. The reading will be locked within 300 sec below the HOLD mode.
3. If you want to exit the HOLD mode, please press the HOLD button to exit


Calibration Function

1. In the shutdown MODE, long-press the "ON/OFF" button and at the same time quickly press the "MODE" button 4-5 times. The display screen will show an internal code. Then release these two keys.
2. Press the Mode button again after you finish step 1. The screen will show 20kg first, then show the zero clearing.
3. Put the weigh calibration on the scale.
4. After the reading becomes stable, press the Mode button. The screen will show PASS, then the calibration has been done.

Notice

1. **O-Ld:** overload. When the screen shows O-Ld, please remove the item to protect the scale.
2. When the scale is out of battery, the battery indicator on the screen will flash. Please replace the batteries.

Documents / Resources

<p>P026 USER MANUAL</p> 	<p>MAXUS P026 Shipping Scale [pdf] User Manual P026 Shipping Scale, P026, Shipping Scale, Scale</p>
--	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.