



MAXVIEW MXL017 Target Software Update Procedure For PC Users User Guide

[Home](#) » [MAXVIEW](#) » MAXVIEW MXL017 Target Software Update Procedure For PC Users User Guide 

MAXVIEW MXL017 Target Software Update Procedure For PC Users User Guide



Contents

- [1 STEP 1 – Download file](#)
- [2 STEP 2 – Update file to control box](#)
- [3 Troubleshooting](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

STEP 1 – Download file

1. You need an empty/blank USB flash memory stick to copy the file onto. Please make sure it is formatted to FAT.
See page 4 for more details.



2. Insert your USB memory stick into an empty slot on your Mac desktop or laptop.



3. Find the software update section on the Maxie website <https://maxview.co.uk/software-updates/>
Left click Download Update File – TARGET



Part No.: MXL017

If you have any issues please contact
Maxview on +44 (01553) 811000 or
email support@maxview.co.uk


> Download Software Instructions - PC

> Download Software Instructions -
MAC


> Download Update File - TARGET



4. Open the ZIP file and copy the hex file.



5. Paste the file onto the USB drive (TARGET)




STEP 2 – Update file to control box



1. Turn on Control Box.



2. Press and hold the SYNC/Update button on the front of the Control Box for approximately 7 seconds until SYNC/update LED illuminates RED.




3. Insert the USB flash memory stick. The SYNC LED will flash GREEN whilst data is being transferred. Transfer can take between 10-60 seconds.



4. When the SYNC LED goes out turn off the Control Box power and remove the USB flash memory stick.



5. Turn power on, update LED will flash RED and GREEN whilst data is written to Control Box memory.



Power on



LED will flash Red & Green

6. When SYNC LED goes out update is complete.




Update complete


Troubleshooting

Formatting USB stick

1. Right click removable disk option (USB stick) in 'computer'




2. Right click and select format




3. Format USB Stick by selecting FAT (Please note any files on USB stick will be erased)



4. Your USB stick is ready for the update file.



Documents / Resources

	<p>MAXVIEW MXL017 Target Software Update Procedure For PC Users [pdf] User Guide MXL017 Target Software Update Procedure For PC Users, MXL017, Target Software Update P rocedure For PC Users, Software Update Procedure For PC Users, Update Procedure For PC Users, Procedure For PC Users, For PC Users, PC Users, Users</p>
---	---

References

- [M Software Updates | Maxview WiFi, Satellite and TV Antennas](#)