



MAXXTER ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function User Manual

[Home](#) » [MAXXTER](#) » MAXXTER ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function User Manual 

MAXXTER ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function



Contents

- [1 Features](#)
- [2 Specifications](#)
- [3 PRODUCT OVERVIEW](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)


Features

- Digital alarm clock with wireless charging function
- Built-in wireless charging module for easy charging of your iPhone X/XS/XR, iPhone 8, Galaxy S8/S7/S6 and other devices with wireless charging function
- Large LCD display shows time, date and temperature
- Dual alarm function allows to set 2 separate wake-up alarms

Specifications

- Input power: 5V/1.5A
- Wireless Output: 5V/1A 5W

PRODUCT OVERVIEW




1. ON/OFF
2. UP
3. MENU
4. DOWN
5. Micro USB Input
6. Time Display
7. Temperature Display
8. Wireless Charging Pad
9. Reset


POWER


Press  to power on. The LED display will show Time and Temperature.

DISPLAY



Press  to switch between different display modes (time/date/alarm1/2/3).

SET TIME



Press  until the display shows the time.

Long press  until the time is blinking. The display panel will show 12H mode or 24H mode.

Press   to select 12H or 24H mode and press  to confirm the mode (if 12H mode is selected, then "PM/AM" will light up at the left corner of display).


Press   to adjust the Hour first.


Press  to confirm the Hour and minutes will blink.

Press   to adjust the minutes.


Press  to confirm the minutes.



SET DATE

Press  until the display shows the date.

Long press  until the year is blinking.

Press   to change the year.

Press  to confirm the year and month will start blinking.

Press   to change the month.


Press  to confirm the month and day will start blinking.


Press   to change the day.



Press  to confirm the date.

SET ALARM



This alarm clock has 3 separate alarm settings, A1, A2 and A3, which can be set individually.

Press  until the display shows "-A1", "-A2" or "-A3".

Long press  until the alarm time is blinking.

Press   to adjust the Hour first.


Press  to confirm the Hour and minutes will blink.

Press   to adjust the minutes.


Press  to confirm the minutes.

Press  to determine the clock.

ENABLE or DISABLE ALARM

Press  until the display shows "-A1", "-A2" or "-A3". "-A1" means alarm 1 is disabled. "0NA1" means alarm 1 is enabled.

Press   to enable or disable the selected alarm (1, 2, or 3).

When one of the alarm times is enables, the display will show the alarm icon  in the lower left corner of display.


On the set alarm time(s), the alarm buzzer will start beeping and the alarm will be blinking. Press any button to stop the sound. If no button is pressed, the sound will stop after 60 seconds.

TEMPERATURE

Press  for 2 seconds to switch between Fahrenheit / Celsius.

POWER-SAVING

When power-saving is enabled, the clock display will automatically turn off after 30 seconds. Press any button to turn it on again.

Short press  to turn on/off the power-saving (“ONSd” means the power saving mode is turned on and “– Sd” means it is turned off).

DISPLAY SETTINGS

The display has 3 settings. Depending on the selected setting, the display will show either the time, the date or alternate between date and time.

Press  button to select DP-1/DP-2/DP-3.

DP-1: Display will alternate between time and date automatically every 4 seconds.

DP-2: User can fix to show date or time.

DP-3: Display shows time. Press  to show date for 4 seconds.





Waste disposal:

Do not deposit this equipment with the household waste. Improper disposal can harm both the environment and human health. For Information about waste collection facilities for used electrical and electronic devices, please contact your city council or an authorized company for the disposal of electrical and electronic equipment.



Documents / Resources

	MAXXTER ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function [pdf] User Manual ACT-DACW-01, Digital Alarm Clock with Wireless Charging Function
	MAXXTER ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function [pdf] User Guide ACT-DACW-01 Digital Alarm Clock with Wireless Charging Function, ACT-DACW-01, Digital Alarm Clock with Wireless Charging Function, Digital Alarm Clock, Alarm Clock, Clock

References

-  [maxxter.biz](https://www.maxxter.biz)