



# MCHOSE X75 V2 Mechanical Keyboard User Manual

[Home](#) » [MCHOSE](#) » MCHOSE X75 V2 Mechanical Keyboard User Manual 

MCHOSE X75 V2 Mechanical Keyboard User Manual


# X75 V2 Mechanical Keyboard

**Warm Reminder:** The product images shown are for illustrative purposes only; the actual product shall prevail.

## Contents

- 1 Product Overview
- 2 Connection Mode
- 3 FN Multimedia Features
- 4 Battery Management
- 5 Documents / Resources
- 5.1 References

## Product Overview



### 1. Indicator Lights:

- Caps Lock Indicator: The CAPS lock light stays on indicating that the keyboard is locked in uppercase mode.
- WIN Key Indicator: This indicator light stays on indicating the lock status of the WIN key, at which time the WIN key disables its function.


## 2. Win/Mac/Android Systems:

- FN + Q = Android system;
- FN + W = Windows system;
- FN + E = Mac mode. The ALT key functions as the Command key, and FN + F1-F12 corresponds to the regular F1-F12 input.
- In Windows system, switching to Mac system will swap the Win key and the left Alt key, with F1-F12 functioning as multimedia keys

## Connection Mode

### 2.4G Wireless Connection:

- Switch the toggle to [2.4G] to enter the 2.4G mode.
- Take out the USB dongle from the dongle slot.
- Insert the USB dongle into the USB port of the computer.
- Manual Pairing dongle (The dongle is default paired): Press and hold [FN + -] for 3 seconds. The indicator will quickly flash to activate the pairing mode. Then, plug the included dongle into the desired device; the indicator light will stay on for 2 seconds after a successful connection.



### Wired Connection:

- Switch the toggle to [OFF] to enter the wired mode.
- Connect the cable to the Type-C port of the keyboard.
- Connect the cable to the USB port of the computer. The keyboard is ready to use.




### Wireless Connection

- Switch the toggle to [B] to enter the wireless mode.
- Press and hold [FN + 1] to start pairing; the indicator light will flash quickly to activate wireless pairing.
- Search for the wireless device name [MCHOSE X75 V2 3.0] or [MCHOSE X75 V2 5.0] on your device, and click to connect, the wireless indicator light will go back to normal after successful pairing.
- Press [FN + 11], [FN + 2@], or [FN + 3#] to switch between devices.




## Lighting Functions





Esc	Long press 3S to restore to default	Right CTRL	Cycle side light speed
\	Backlight mode switching	/ ?	Switch side light color
TAB	Backlight color switching	Right ALT	Cycle through the side light brightness
↑	Backlight brightness +	B	Switch the status light to battery mode
↓	Backlight brightness -	Z	Switch the color of the status light
←	Backlight Speed-	Left SHIFT	Switch the status light mode
→	Backlight Speed+	Right SHIFT	Switch side light mode

## FN Multimedia Features

### Win system



Button	Multimedia combination function	Multimedia functions (single press)
F1	Homepage	F1
F2	Mail	F2
F3	Switch window	F3
F4	File explorer	F4
F5	Light brightness -	F5
F6	Light brightness +	F6
F7	Previous song	F7
F8	Play/Pause	F8
F9	Next song	F9
F10	Mute	F10
F11	Volume-	F11
F12	Volume+	F12

Mac System		
Button	Multimedia combination function	Multimedia functions (single press)
F1	F1	Screen brightness -
F2	F2	Screen brightness +
F3	F3	Conversion Window
F4	F4	Return to Desktop
 + F5	F5	Light brightness -
 + F6	F6	Light brightness +
F7	F7	Previous song
F8	F8	Play/Pause
F9	F9	Next song
F10	F10	Mute
F11	F11	Volume-
F12	F12	Volume+

## Battery Management

### 1. Battery Status

- In 2.4G/Wireless mode (the USB dongle is not plugged), press [FN + B] to display the keyboard's battery level.
  - As the battery depletes, the green light will gradually decrease. A full red indicator shows low battery.
- ?[Status Indicator Light] Full green indicates high battery.
- ?[Status indicator light] All red indicates low battery.


### 2. Charging Method

- In any mode, connect the keyboard to a computer with the provided cable to charge it.
- During charging, the [Charging Indicator Light] will show a flowing light effect. Once fully charged, the [Charging Indicator Light] will show a steady green light.

### 1. Sleep Function

In wireless mode, the keyboard backlight will automatically turn off after 3 minutes of inactivity.

If there's no action for 30 minutes, the wireless/2.4G connection will be disconnected. Press any key to reconnect.



Note: This device has been tested and complies with the limits for Class B digital devices under Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in residential installations.

This device generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this device does cause harmful interference to radio or television reception (which can be determined by turning the device off and on), we encourage the user to try one or more of the following measures to correct the interference:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the responsible party could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions

- (1) This device may not cause harmful interference.
- (2) This device must accept any interference received, including interference that may cause undesired operation.



## CHARGING INSTRUCTIONS



1. It is recommended to charge the keyboard only via a computer USB port.
2. Avoid using substandard or non-compliant power adapters to charge the keyboard.
3. Avoid using over-voltage or over-current power adapters for charging.
4. Keep the keyboard away from high-temperature devices while charging.
5. Please turn off the power switch if the device will not be used for an extended period.

These charging instructions also apply to other rechargeable devices (keyboard/mouse/headphones/speakers, etc.).

## WARRANTY CARD

Thank you for purchasing our product. Please contact us if there are any quality issues within the warranty period.

Please provide this warranty card so we can provide comprehensive after-sales service.

Product Items: \_\_\_\_\_

Customer Name: \_\_\_\_\_

Serial No. : \_\_\_\_\_

Contact Address: \_\_\_\_\_

Purchase Date: \_\_\_\_\_

TEL / E-mail: \_\_\_\_\_

Purchase Channel: \_\_\_\_\_

Postcode: \_\_\_\_\_

## Documents / Resources



[MCHOSE X75 V2 Mechanical Keyboard](#) [pdf] User Manual

X75 V2 Mechanical Keyboard, X75, V2 Mechanical Keyboard, Mechanical Keyboard, Keyboard

## References

- [User Manual](#)

[Manuals+](#). [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.