



Home » MCombo » MCombo 6151-4663 Modular Sofa Owner's Manual 🥦



Contents [hide]

- 1 MCombo 6151-4663 Modular Sofa
- **2 SAFETY GUIDELINES**
- 3 Pre-Assembly Introduction
- **4 ASSEMBLY INSTRUCTIONS**
- 5 Product Parameters
- 6 Assembly of Chair Frame
- 7 Place the Cushion.
- **8 CARE AND MAINTENANCE**
- 9 RETURN/ REPLACEMENT POLICY
- 10 FAQs
- 11 Documents / Resources
 - 11.1 References



MCombo 6151-4663 Modular Sofa



Specifications

• Product Model No.: 6151-4663

• Package Quantity: 2

• Carton Dimensions: Box 1 – 36.4×36.4×8.7 inch, Box 2 – 31.5×17.7×12.6 inch

• Weight Capacity: 330 lbs

Safety Guidelines:

Mandatory: Read and follow the information in the owner's manual.

Warning: Weight capacity is 330 lbs; do not put your weight against the chair back. Indoor use only.

Symbols Information: Follow the symbols on the product for warnings and actions. Keep labels intact.

Assembly Instructions

Pre-Assembly Introduction

- Teamwork/2-People Recommended for transport and assembly.
- Avoid Scratches: Use a cardboard or carpeted area during assembly.
- Level & Flat Surface: Ensure the product rests evenly on a flat surface.
- All required tools are included except a Phillips Screwdriver.

Product Assembly

- 1. **Step 1:** Combine Connecting Rod with Back Frame using Fixing Rod and secure with Screw.
- 2. Step 2: Attach Chair Leg to Seat Frame using screws.
- 3. **Step 3:** Secure Connecting Rod and Seat Frame with screws and Allen wrench. Secure Back Frame and Seat Frame with screws and Allen Wrench.

www.mcombo.com / sales@mcombo.com





Hello,

Thank you for choosing MCombo@ Let's get started

PURCHASER'S AGREEMENT

By accepting delivery of this product, you promise that you will not change, alter, or modify this product or remove or render inoperable or unsafe any guards, shields, or other safety features of this product.

You will not refuse or neglect any retrofit kits that MCombo may provide to enhance and preserve the safe use of this product.

SAFETY GUIDELINES

Mandatory

Read the safety and other instructions thoroughly before using your MComboeproductt-Failure to follow the guidelines, warnings in this manual and those located on your product can result in personal injury or product damage and will void the product warranty- ty. Keep this manual for future reference.

Warning

- To prevent suffocation, keep plastic bags away from children-
- Weight Capacity: 330 lbs-
- Do not use outdoors. INDOOR IJSE ONLY-
- To avoid tipping over, do not put your weight against the back of the chair.
- Do not stand, sit, or place extra weight on the arms, back, or open footrest.
- Do not use this product if it is damaged. Do not use attachments or substitute parts-
- Avoid exposing upholstered chairs to burning cigarettes or cigars, open flames, and high temperatures.
- Do not operate the unit until the back is installed and locked.
- The chair is intended for a single occupant, not exceeding 330 pounds.s- Do not operate the chair with more than one occupant in or on any part of the chair.
- If you give this product to someone else, you must include this owner's manual.

Symbols Information

The symbols below represent labels used on the product to identify warnings, mandatory actions, and prohibited actions. You need to read and understand these symbols completely. Do not remove these labels from your product. Please note that not all the symbols may be used on your chair.













Disclaimer

Make sure you read and understand this manual completely before using your MCombo Product. We are not and cannot be held responsible for any damage or injury incurred due to improper or unsafe use of the MCombo Product. We specifically disclaim responsibility for any bodily injury or property damage that may occur during any use that does not comply with applicable federal, state, or local laws or ordinances.

Pre-Assembly Introduction

Teamwork/2-People Recommended

Always have at least two people to help with transporting and assembling the product to avoid potential injury and/or damage.





Avoid Scratches

Use cardboad or carpet area when assembling the product to prevent scratches.





Level & Flat Surface

Make sure the product rests on a flat and level surface so that each legs touch the floor evenly.





Allen Wrench is included in the package to help you install the product. But the tools, like Phillips Scewdriver is not included.






ASSEMBLY INSTRUCTIONS

Notice

- Please read these instructions thoroughly before using.
- Please contact us (See "MCombo Customer Support" on Page) immediately if anything is missing or damaged.


Product Parameters

Specification	Description
Product Model No.	6151-4663
Package Quantity	2
Carton Dimension	6151-4663-1: 36.4x36.4x8.7 inch 6151-4663-2: 31.5x17.7x12.6 inch
Weight Capacity	330lbs
Package Contains	Box 1 of 2: Back Frame, Seat Frame, Connecting Rod, Fixing Rod, Chair Leg, Seat Cushion, Screw Pack, Instructions Box 2 of 2: Back Cushion




Step 1

1 Use 2 Fixing Rod $\mbox{\#D}$ to combine Connecting Rod $\mbox{\#C}$ with Back Frame $\mbox{\#B}.$












Attach the Chair Leg #E to the Seat Frame #A using 3 screws #H.










Place the Cushion.







Now you can relax your body on this chair and even decorate your living room.



CARE AND MAINTENANCE

Your MCombo product will provide years of superior performance and satisfaction with regular care and maintenance. To maintain the finish quality of your "assistant", please follow the guidelines and cleaning procedures provided below.

Notice

- Do not place your chair in direct sunlight, as sunlight causes fading.
- Do not smoke cigarettes while seated in or using your chair.
- Avoid extreme changes in temperature by arranging the chair away from radiators, heat, and air vents.
- Do not use solvent-type cleaners to spot clean.
- Do not saturate fabric.
- Please be careful that a pet scratch may cause the fabric or leather to break.

Fabric Care

- Inspect the fabric on a regular basis for any pulls, tears, or gaps.
- Frequent vacuuming or light brushing with a nonmetallic, stiff-bristle brush to remove dust and grime is recommended.
- When liquid spills onto the fabric, please immediately wipe off the liquid spills with a dry or lightly dampened clean white cloth, sponge, or paper towel.

Electronics Care

- Inspect all wiring harnesses to make sure they are not damaged or stuck under the chair.
- Keep all the electronics free from moisture and temperature extremes.
- Check electrical components frequently for signs of corrosion and replace as necessary.
- Contact MCombo Customer Support if damage is present; do not fix it by yourself 3.

Faux Leather Care

- Never use detergents, polishes, preservatives, saddle soap, abrasive brushes, or scrubbers. They can remove natural oils.
- Dust, vacuum, or wipe leather down regularly with a clean, dry microfiber cloth for routine maintenance.
- Do not place in direct sunlight; it will lighten or discolor leather over time.
- If spills occur, immediately soak up any liquids with an absorbent cloth and allow to air dry.
- Thorough cleaning by a leather specialist only.
- For more stubborn dust, dampen the cloth with distilled water. Make sure that the cloth is not soaking wet. Never let water soak into leather.

Wood Part Care

- Keep the wood part of a fireplace and heating and cooling vents away from moisture sources, such as humidifiers, and out of direct sunlight.
- Daily exposure to heat or sunlight may fade the wood finishes and dry the wood,

which can create cracks over time.

Metal Care


- Avoid bumping, and handle gently when moving.
- Avoid touching hard metal parts, such as fruit knives, keys, etc., to avoid scratches.
- Do not fold too fast to ensure that the folded part is not damaged.
- Avoid the direct exposure of sunlight, so as to avoid paint discoloration, dry cracking and peeling of colored paint layer, oxidation, and deterioration of metal.
- Avoid placing chairs in damp places, avoid cleaning metal furniture with boiling water,
 wipe with a damp cloth, but do not rinse with running water.

Disposal & Recycling

Your power recliner sofa must be disposed of according to applicable local and national statutory disposal regulations. Contact your local waste disposal agency for information on the proper disposal of recliner sofa packaging, metal/wood frame components, fabric, and electronic components.

Notice

- For products beyond the limited manufacturer warranty period and scope, MComboe can also provide replacement service, but a basic charge will be applied according to the circumstances.
- The warranty only applies to MComboe products and does not include any accessories or enhancements.
- Warranties are only valid in the 48 contiguous United States and are contingent upon the consumer operating the product according to the corresponding instruction manual.



CONSUMER WARRANTY LIMITATIONS AND EXCLUSIONS

All warranties begin on the date of delivery.

- All warranties are to the original purchaser from MCOMBO@ ONLY.
- MCOMBO@ will replace the defective parts or send a replacement product, provided that the warranty parts have not been subjected to misuse, abuse, or improper service by the consumer.
- Exclusions also include components with damage caused by:
 - Contamination
 - Abuse, misuse, accident, or negligence
 - Commercial use, or use other than normal
 - Improper operation, maintenance, or storage

NOTE:

- MCOMBO@ will pay standard shipping rates on all warranted parts for the first year.
- We can also sell you replacement parts for a discount price when your product is out of warranty.

RETURN/ REPLACEMENT POLICY

Notice

- Why don't we recommend returning the item by yourself?
- Huge cost- UPS/FedEx oversized fee.
- Need you to take the box to the UPS/FedEx facility.

Return/ Replacement Policy

- MCOMBO'
- All of the products come with a 30-day return/replacement policy. During this time, we
 will cover the shipping cost of return and replacement for defective and damaged
 products, through providing a pre-paid return label or pick-up service for customer
 convenience.

NOTE:


• Please keep the original packaging in case the product needs to be returned. If the

original packaging is not available, the newly found packaging needs to meet the following size standard:

- UPS/FedEx packaging size standard: (width + height) 2+ length < 128 inches.
- Please disassemble the product before you return it, otherwise there will be a huge cost as oversized, and it could even exceed your order amount.
- Please do not purchase a return label for a damaged/defective product by yourself.
- If you have any problem returning the product, please contact us immediately, and we will do our best to help you with a reasonable solution.
- The customer is responsible for freight costs unless the chair is defective. Chairs
 returned due to being refused delivery by the customer or deemed undeliverable by
 the freight carrier are subject to fees for a 20% restocking fee.

MCOMBO CUSTOMER SUPPORT

If for any reason, we have fallen short of your expectations, or if you have any questions or suggestions, please refer to the following contact information. We will do our best to work with you to make sure you are entirely satisfied.



FAQs

Q: What is the weight capacity of the sofa?

A: The weight capacity of the sofa is 330 lbs.

Q: Are all assembly tools included in the package?

A: Yes, all assembly tools are included except for the Phillips Screwdriver.

Documents / Resources



MCombo 6151-4663 Modular Sofa [pdf] Owner's Manual

6151-4663, 6151-4663 Modular Sofa, 6151-4663, Modular Sofa, Sofa

References

User Manual

• 6151-4663, 6151-4663 Modular Sofa, MCombo, Modular Sofa,

Save my name, email, and website in this browser for the next time I comment.

■ MCombo Sofa

Leave a comment

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.