




MEE audio C20PTZ Professional USB Camera with Pan-Tilt-Zoom Functionality User Manual

[Home](#) » [mee audio](#) » MEE audio C20PTZ Professional USB Camera with Pan-Tilt-Zoom Functionality User Manual 

MEE audio C20PTZ Professional USB Camera with
Pan-Tilt-Zoom Functionality User Manual

USER MANUAL



PROFESSIONAL USB CAMERA with PAN-TILT-ZOOM FUNCTIONALITY

Model: C20PTZ

SETUP GUIDE



To learn more about using your camera, scan the QR code or enter the URL below into your web browser: MEEaudio.com/CameraHelp



Contents

1 Getting Started

1.1 Installing Batteries

1.2 Placement Option 1: Table or Tripod

1.3 Placement Option 2: Ceiling Mount

2 Setup

2.1 Video Setup

2.2 Microphone Setup

3 Functionality

3.1 Camera Overview

3.2 Using the Remote Control

4 Additional Information

4.1 Safety and Care

4.2 Disposal and Recycling

5 Warranty

5.1 Warnings


6 Documents / Resources

6.1 References

7 Related Posts

Getting Started

Installing Batteries





Install 2x AAA batteries in the battery compartment located on the back of the remote control

Note: Batteries not included

Placement Option 1: Table or Tripod

Place the camera on a flat, stable surface or on attach to a compatible tripod



Placement Option 2: Ceiling Mount

The camera can also be mounted on a ceiling using the included mounting kit

Mounting Kit Contents




1x mounting plate



3x drywall anchor




3x screw



Use the included hardware to attach the mounting plate to the ceiling as shown. Point the arrow on the mounting plate in the direction you want the camera to face.

Caution: If you're mounting the camera on drywall, be sure to use the included drywall anchors.



Push the camera against the mounting plate and rotate it clockwise.

Caution: Always hold the camera by the base and avoid touching the lens



Setup

Connect the camera to your computer's USB port

Note: The camera will perform an automatic scan across its full range of motion when connected

Video Setup



This camera is a plug-and-play device and does not require additional software but you may have to select it as the default video device in your video recording or teleconferencing app:




For more information about using your camera with different applications, scan the QR code or enter the URL below into your web browser: MEEaudio.com/CameraHelp

Microphone Setup

To use the integrated microphone, you may also need to select it from your video recording or teleconferencing app:




This camera also supports up to two external 3.5mm microphones. To use external microphones, simply plug them into the 3.5mm inputs on the back of the camera.




Functionality

Camera Overview




Using the Remote Control

Note: Aim the remote at the IR sensor on the base of the camera.



- A Power on/off *
- B Audio mute **
- C Pan up
- D Pan left
- E Pan right
- F Pan down
- G Reset camera position and zoom
- H Zoom in
- I Zoom out
- J Vertical flip ***
- K Increase volume **
- L Decrease volume **



* The Power on/off button on the remote and on the camera body work independently. If the camera is powered off via the Power button on the camera body, the red Power indicator light will light up to indicate that the master power switch has been used and the remote is disabled

** Affects both the built-in microphones and any external microphones connected to the 3.5 mm microphone input(s). The Mute indicator light on the base of the camera will be red while the microphones are muted

*** For placement on ceilings

Additional Information

Safety and Care

- Avoid touching the camera lens with your fingers, sharp objects, and coarse materials
- Use a clean, soft cloth to clean the camera if needed. Do not use chemical cleaners.
- Avoid dropping the camera as impact may damage its internal components or scratch its lens
- There are no user replaceable/reparable parts in this device. Disassembling it will void your warranty.

Disposal and Recycling

Dispose of this product in accordance with all local laws and regulations. Because this product contains electronic components, it must be disposed of separately from household waste. Contact local authorities to learn about disposal and recycling options.

Warranty

MEE audio products purchased from authorized resellers are covered by a 1-year manufacturer warranty. For more information, visit

Warnings

This device is designed and manufactured to operate within its defined design limits. Misuse may result in electric shock or fire. Read and follow these instructions carefully.

- To prevent fire or shock hazards, do not expose this unit to rain or moisture. If the device comes in contact with liquids, quickly wipe away. If submersed in water, do not turn the device on until completely dried.

Note: liquid submersion voids the warranty.

- Only use attachments/accessories specified by the manufacturer

Changes or modifications to this unit not expressly approved by MEE audio could void the user's authority to operate the equipment.

Keep the device and packaging out of reach of children.

For Additional Support

View MEEaudio.com/CameraHelp for easy-to-follow setup videos and the latest troubleshooting information.

Still Have Questions?

Email Support: support@meeaudio.com

MEE audio and its logo are registered trademarks of S2E, Inc. All rights reserved.

Microsoft® Windows® is a registered trademark of Microsoft Corporation in the United States and other countries. ©2018 Google LLC All rights reserved. Chrome OS™ operating system is a trademark of Google LLC. macOS® is a registered trademark of Apple Inc.

All other trademarks are the property of their respective owners.





WARNING: Cancer and Reproductive Harm –





www.P65Warnings.ca.gov

For more information about this warning visit MEEaudio.com/prop65

Documents / Resources

 <p>PROFESSIONAL USB CAMERA with PAN-TILT-ZOOM FUNCTIONALITY</p> <p>NEW COPY</p>  <p>MEE audio</p>	<p>MEE audio C20PTZ Professional USB Camera with Pan-Tilt-Zoom Functionality [pdf] User Manual</p> <p>C20PTZ, Professional USB Camera, with Pan-Tilt-Zoom Functionality</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

-  [Webcam Support Guide](#)
-  [Prop 65](#)
-  [MEE audio | Support](#)
-  [P65Warnings.ca.gov](#)

Manuals+.