

Melodyblue 1870000694A1 L Shaped Gaming Computer Desk **Installation Guide**

Home » Melodyblue » Melodyblue 1870000694A1 L Shaped Gaming Computer Desk Installation Guide 🖺



Contents

- 1 Melodyblue I870000694A1 L Shaped Gaming Computer **Desk**
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 PARTS**
- **5 INSTRUCTION**
- **6 ASSEMBLY**
- 7 Documents / Resources
- 7.1 References
- **8 Related Posts**

Melodyblue

Melodyblue 1870000694A1 L Shaped Gaming Computer Desk



Product Information

Specifications

• Model: I870000694A1

• Product Name: L Shaped Computer Desk

Product Usage Instructions

Tools Required (not included)

The following tools are required for assembly:

• 2 Persons

Assembly Steps

Step 1: Gather the Required Parts

Make sure you have all the necessary parts for assembly:

- 1 x 1
- 2 x 1
- 3 x 1
- 4 x 1
- 5 x 4
- 6 x 2
- 7 x 1
- 8 x 2

- 9 x 1
- 10 x 2
- 11 x 1
- 12 x 1
- 13 x 2
- 14 x 1
- 15 x 1
- 16 x 1
- 17 x 1
- 18 x 2
- 19 x 2
- 20 x 2
- 21 x 1
- 22 x 2
- 23 x 1
- 20 X
- A
- B
- C
- D
- M6*50mm
- 8 M6*45mm
- 24 M6*30mm
- 16 M6*25mm
- 8 E
- F
- G
- H
- M6*12mm
- 21 I
- 1 M3.5*12mm
- 2 M6*22*20mm
- 6 S4

Step 2: Start Assembly

Follow the steps below to assemble the L Shaped Computer Desk:

- 1. Attach part A to part B using 6 screws (B x 6, H x 6).
- 2. Attach part B to part H using 5 screws (B x 5, H x 5).
- 3. Attach part B to part C using 4 screws (B x 4, C x 4).
- 4. Attach part C to part D using 3 screws (B x 3, C x 3).
- 5. Attach part B to part E using 2 screws (B x 2, E x 2).
- 6. Attach part E to part F using 2 screws (E x 2, F x 1).
- 7. Attach part F to part G using 1 screw (F x 1, G x 2).

- 8. Attach part G to part H using 2 screws (G x 2, H x 5).
- 9. Attach part H to part I using 4 screws (H x 4, I x 1).
- 10. Attach part I to part B using 4 screws (A x 8, B x 4).
- 11. Attach part B to part E using 4 screws (B x 4, E x 2).
- 12. Attach part E to part D using 8 screws (E x 4, D x 8).
- 13. Attach part D to part E using 12 screws (D x 8, E x 12).
- 14. Attach part E to part I using 2 screws (E x 2, I x 1).
- 15. Attach part I to part E using 1 screw (I x 1, E x 4).

FAQ

Q: What tools are required for assembly?

A: You will need two persons for assembly. Tools such as a screwdriver and Allen wrench are not included and must be provided separately.

Q: How many parts are included in the package?

A: The package includes various parts numbered from 1 to 23, as well as screws and fasteners.

Q: Can the L Shaped Computer Desk be disassembled for moving?

A: Yes, the desk can be disassembled for easier transportation. Simply follow the assembly instructions in reverse order.


L Shaped Computer Desk


TOOLS






PARTS








HARDWARE





INSTRUCTION































ASSEMBLY





















COMPLETE





Melodyblue 1870000694A1 L Shaped Gaming Computer Desk [pdf] Installation Guide 1870000694A1, 1870000694A1 L Shaped Gaming Computer Desk, L Shaped Gaming Computer Desk, Gaming Computer Desk, Desk

References

• User Manual

Manuals+, Privacy Policy