



Mercury TD-W8960 Modem Router User Manual

[Home](#) » [Mercury](#) » Mercury TD-W8960 Modem Router User Manual 

Contents

- [1 Mercury TD-W8960 Modem Router](#)
- [2 TP Link TD-W8960 Fibre Configuration](#)
 - [2.1 Log into the gateway](#)
- [3 How to add correct settings for the Mercury network](#)
- [4 Ensure the following settings are changed](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



Mercury TD-W8960 Modem Router



TP Link TD-W8960 Fibre Configuration

Using your own router? No worries, we've got you covered!

Log into the gateway

1. Connect your device to the router preferably via cable.
2. Open a web browser
3. Type the following in the address bar at the top: 192.168.1.1
4. Default Username: admin
5. Default Password: admin
6. This should then give you access to the router's User Interface.

If the password is incorrect you will need to factory reset the router by pushing and holding the Inset Reset' button for 10 seconds.


How to add correct settings for the Mercury network

1. From the menu on the left select Advanced Setup.
2. From the sub-menu select Layer 2 Interface.
3. Then select ETH Interface.
4. In this page, remove any existing ETH Interfaces.
5. Select Add.
6. Select the following ETH Interface ETH3/LAN4.
7. Click Apply/Save
8. From the menu on the left select WAN Service.

Ensure the following settings are changed

1. PPP Username: Your Mercury Account Number@mercurybroadband.co.nz
2. PPP password: password
3. PPPoE Service Name: (Left Blank)
4. Authentication Method: Auto
5. MTU: 1492
6. Click Next
7. Click through the next couple of pages
8. Select Save/Apply/

Documents / Resources

	Mercury TD-W8960 Modem Router [pdf] User Manual TD-W8960 Modem Router, TD-W8960, Modem Router, Router
---	--

