

MERCUSYS AX3000 Wi-Fi 6 Bluetooth 5.2 PCle Adapter **Installation Guide**

Home » MERCUSYS » MERCUSYS AX3000 Wi-Fi 6 Bluetooth 5.2 PCle Adapter Installation Guide Ta

Contents

- 1 MERCUSYS AX3000 Wi-Fi 6 Bluetooth 5.2 PCle **Adapter**
- 2 Specifications
- 3 Connect to a Computer
- **4 Install Bluetooth Driver**
- 5 Pair With Bluetooth Devices
- 6 FAQ
- 7 More Information
- 8 Documents / Resources
 - 8.1 References



MERCUSYS AX3000 Wi-Fi 6 Bluetooth 5.2 PCle Adapter




Specifications

• Product: Bluetooth Adapter

• Compatibility: Windows systems

• Driver Download: https://www.mercusys.com/support

Connect to a Computer



- Disable all existing Bluetooth devices (both built-in and third-party) from the Device Manager on Windows.
- Insert the adapter into a USB port on your computer directly.

Install Bluetooth Driver

- Download the latest driver at https://www.mercusys.com/support
 - Tip: For Windows 11/10/8.1 system, the driver installation will automatically start when connected to the internet. If not, please download the driver manually.
- Extract the downloaded file and run the setup.exe to start driver installation.
- Follow the instructions to complete installation.
- · Once the process is finished, restart your computer.

Notes:

- Your Bluetooth USB adapter will be listed in the Device Manager when the driver is installed correctly.
- If the driver installation fails, disable the antivirus software and firewall, then try again.
- In Windows 7, if a Windows Security message pops up, refer to https://www.mercusys.com/faq-912

Pair With Bluetooth Devices



- Right click the [®] (Bluetooth) icon on the taskbar.
 - Note: If the Bluetooth icon is not displayed, refer to FAQ > Q1.
- Select Add a Bluetooth Device or Add a Device to scan for available devices.
- Select your Bluetooth device from the list and follow the onscreen instructions to complete pairing.

Note: Make sure your device's Bluetooth is enabled and discoverable.

FAQ

Frequently Asked Questions

- Q1. What should I do if the Bluetooth icon doesn't appear?
 - A1. Make sure you have turned on the Bluetooth in Windows settings.
 - A2. If there are other Bluetooth devices on the computer, disable them in Device Manager, then insert the
 adapter and try again.
- Q2. Why the adapter is not working with my Bluetooth device?
 - A1. Make sure your device has BLUETOOTH function.
 - A2. Make sure you have installed the latest Bluetooth driver on the computer. You can check the
 published driver versions from https://www.mercusys.com/support

 A3. For devices with non-standard Bluetooth protocols, such as Logitech Mouse, there may be some compatibility problems.

More Information

Scan



• http://www.mercusys.com

For technical support, the user guide and more information, please visit https://www.mercusys.com/support

Images may differ from your actual product. ©2024 MERCUSYS 7107500316 REV1.0.0

Documents / Resources

- 25 ER 26 ER 26 ER

MERCUSYS AX3000 Wi-Fi 6 Bluetooth 5.2 PCle Adapter [pdf] Installation Guide MA530, AX3000 Wi-Fi 6 Bluetooth 5.2 PCle Adapter, AX3000, Wi-Fi 6 Bluetooth 5.2 PCle Adapter, Bluetooth 5.2 PCle Adapter

References

- Welcome to MERCUSYS
- Welcome to MERCUSYS
- What should you do if Windows 7 cannot verify the digital signature of MERCUSYS driver software Welcome to MERCUSYS
- Support-Welcome to MERCUSYS
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.