

MERCUSYS
ME10 Wi-Fi 4
Range Extender



MERCUSYS ME10 Wi-Fi 4 Range Extender Instructions

[Home](#) » [MERCUSYS](#) » MERCUSYS ME10 Wi-Fi 4 Range Extender Instructions 

Contents

- [1 MERCUSYS ME10 Wi-Fi 4 Range Extender](#)
- [2 STATEMENT OF COMPLIANCE](#)
- [3 Specifications](#)
- [4 Product Usage Instructions](#)
- [5 Frequently Asked Questions \(FAQ\)](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)

MERCUSYS

MERCUSYS ME10 Wi-Fi 4 Range Extender



STATEMENT OF COMPLIANCE

We, MERCUSYS TECHNOLOGIES CO., LTD. hereby declare that the device complies with the applicable security requirements in Schedule 1 of the Product Security and Telecommunications Infrastructure (Security Requirements for Relevant Connectable Products) Regulations 2023 (the “Regulations”).

We will provide security updates for this product during the support period. The defined support period will end in 3 years after the product’s last end-of-life date. Up-to-date information concerning the defined support periods for the entire TP-Link product range and the products that have entered End of Life, please visit:

<https://www.mercusys.com/uk/psti>

Person responsible for making this declaration:

Signature

Name: Tan Yinghao

Function: Product Director

Specifications

- **Manufacturer:** MERCUSYS TECHNOLOGIES CO., LTD.
- **Address:** 3rd Floor, Building R1-B, No. 23, Gaoxin 4th Road, South Hi-Tech Park, Nanshan, Shenzhen, P.R. China
- **Product Type:** Wi-Fi 4 Range Extender
- **Product Model:** ME10
- **Product Version:** V1

Product Usage Instructions

• Step 1: Unboxing

Unpack the ME10 Wi-Fi Range Extender from the box.

• Step 2: Placement

Place the range extender within the existing Wi-Fi network coverage area but closer to the dead zones you want to eliminate.

- **Step 3: Power On**

Plug the range extender into a power outlet and wait for it to power on.

- **Step 4: Configuration**

Connect to the ME10 Wi-Fi network using a computer or smartphone. Follow the on-screen instructions to complete the setup process.

- **Step 5: Testing**

Test the extended Wi-Fi coverage by moving around your home or office to ensure a strong and stable connection in previously weak areas.

Frequently Asked Questions (FAQ)

Q: How can I reset the ME10 Range Extender?

A: To reset the extender, locate the reset button on the device and hold it down for 10 seconds until the LED lights start flashing.


Q: Can I use multiple ME10 Range Extenders in my network?

A: Yes, you can use multiple extenders to further expand your Wi-Fi coverage. Ensure each extender is appropriately placed within range of the main router.

Q: How do I update the firmware of the ME10 Range Extender?

A: Visit the official MERCUSYS website and navigate to the support section for the ME10 model. Download the latest firmware version and follow the instructions provided to update your device.

Documents / Resources

	MERCUSYS ME10 Wi-Fi 4 Range Extender [pdf] Instructions ME10 Wi-Fi 4 Range Extender, ME10, Wi-Fi 4 Range Extender, Range Extender, Extender
---	--

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.