

meross MSH300 Smart Wi-Fi Hub



## meross MSH300 Smart Wi-Fi Hub Installation Guide

[Home](#) » [Meross](#) » meross MSH300 Smart Wi-Fi Hub Installation Guide 

### Contents

- [1 meross MSH300 Smart Wi-Fi Hub](#)
- [2 Installation Guide](#)
- [3 Warranty](#)
- [4 Operating Frequency](#)
- [5 Documents / Resources](#)
  - [5.1 References](#)

meross


meross MSH300 Smart Wi-Fi Hub



## Meross app



## Package Contents




If you find any part missing in the package, please contact us at [https://www.meross.com/support/Email\\_Support](https://www.meross.com/support/Email_Support), and we will provide a proper solution for you.

## Installation Guide

1. Download the Meross app.
2. Follow the instructions in the Meross app to complete the setup.

## LED and Button Rules



### 1. Hub Status LED

**Solid amber:** Initiating/Reset/Firmware upgrading.

- **Flashing amber and green:** Configuration mode.
- **Flashing green:** Pairing mode/Connecting to Wi-Fi/Disconnected from Wi-Fi.
- **Solid green:** Connected to Wi-Fi with an internet connection.
- **Solid red:** No internet connection.

## Hub Button

- Enter pairing mode: Double-click the button.
- Restore factory settings: Press and hold for 5 seconds.
- The LED will flash amber and green, entering pairing mode.

## Warranty

Meross products are covered by a 24-month limited warranty from the date of purchase. Please visit <https://www.meross.com/support/warranty> for a detailed warranty policy and product registration.

## Support

For technical support, user guide, warranty, FAQs, and other information, please visit <https://www.meross.com/support>.

## Declaration Of Conformity

Meross hereby declares that the device complies with essential requirements and other relevant provisions of directives 2014/53/EU, 2009/125/EC, 2011/65/EU. The original EU Declaration of Conformity may be at <https://www.meross.com/support/eudoc>. Meross hereby declares that the device complies with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at <https://www.meross.com/support/ukca>.

## Operating Frequency

No restrictions exist in the use of radio frequencies or frequency bands in all EU member states, EFTA countries, Northern Ireland and Great Britain.

- Operating Frequency / Max Output Power: 2400MHz~2483.5MHz / 20dBm 433.050MHz~434.790MHz / 10dBm

## Disclaimer

1. The function of this smart device is tested under a typical circumstance described in our specifications. Meross does NOT guarantee that the smart device shall perform the same as described under all circumstances.
2. By using third-party services including but not limited to Amazon Alexa, Google Assistant, Apple HomeKit and SmartThings, customers acknowledge that Meross.

## Documents / Resources

### Package Contents

\*If you find any part missing in the package, please contact us at [https://www.meross.com/support/Email\\_Support](https://www.meross.com/support/Email_Support), we will provide proper solution for you.

English

### Installation Guide

1. Download the Meross app.
2. Follow the instructions in the Meross app to complete the setup.

### LED and Button Rules

① Hub Status LED  
Solid amber:  
Initiating/Reset/Factory  
Resetting.  
Flashing amber and green:  
Configuration mode.  
Flashing green:  
Ready/Connecting to  
Wi-Fi (Disconnected from Wi-Fi).  
Solid green:  
Connected to Wi-Fi with an internet connection.  
Solid red:  
No internet connection.

② Hub Button  
Enter pairing mode: Double-click the button.  
Restore factory settings: Press and hold for 8 seconds.  
The LED will flash amber and green, entering pairing mode.

### Safety Information

- Do not attempt to disassemble, repair, or modify the device.
- Please contact seller for replacement if there is any damage caused by transportation.
- Indoor use only.

### Warranty

Meross products are covered by a 24-month limited warranty from the date of purchase. Please visit <https://www.meross.com/pages/Support> for detailed warranty policy and product registration.

### Support

For technical support, user guide, warranty, FAQs, and other information, please visit: <https://www.meross.com/support>.

### Declaration Of Conformity

Meross hereby declares that the device is in compliance with essential requirements and other relevant provisions of directives (2014/53/EU, 2014/30/EU, 2014/35/EU, the original UK Declaration of Conformity may be found at <https://www.meross.com/pages/Support>).  
Meross further declares that the device is in compliance with the essential requirements and other relevant provisions of the Radio Equipment Regulations 2017. The original UK Declaration of Conformity may be found at <https://www.meross.com/support/ukdof>.

### Operating Frequency

No restrictions exist in the use of radio frequency or frequency bands in all EU member states, EFTA countries, Northern Ireland and Great Britain.  
Operating Frequency / Max Output Power  
2400MHz-2483.5MHz / 100mW  
433.000MHz-434.790MHz / 100mW

### Disclaimer

1. The function of this smart device is tested under a typical environmental condition in our specifications. Meross does NOT guarantee that the smart device will perform exactly the same as described under all circumstances.
2. By using third-party services including but not limited to Amazon Alexa, Google Assistant, Apple HomeKit and SmartThings, customers acknowledge that Meross

## meross MSH300 Smart Wi-Fi Hub [pdf] Installation Guide

### MSH300 Smart Wi-Fi Hub, MSH300, Smart Wi-Fi Hub, Wi-Fi Hub, Hub

## References

- User Manual