



Mesqool CR1008 Digital LED Alarm Clock Instruction Manual

[Home](#) » [Mesqool](#) » Mesqool CR1008 Digital LED Alarm Clock Instruction Manual 

Mesqool CR1008 Digital LED Alarm Clock Instruction Manual




Contents

- 1 CREATE YOUR PERFECT SLEEP ENVIRONMENT
- 2 Chapter 2 POWERING ON
- 3 Chapter 3 TIME SETTING
- 4 Chapter 4 ALARM SETTING
- 5 Chapter 5 DIMMER
- 6 Chapter 9 WARRANTY
- 7 Documents / Resources
 - 7.1 References
- 8 Related Posts

CREATE YOUR PERFECT SLEEP ENVIRONMENT

Chapter 1 LOCATION OF CONTROLS




- 1. PM Indicator
- 2. DST Indicator
- 3. Alarm Indicator
- 4. Dimmer Slider
- 5. Time Format Slider





6. Alarm Volume Slider
7. Alarm ON/OFF Slider
8. Set Time Button
9. Alarm Pause Button
10. Set Alarm Button
11. DC IN
12. Speaker
13. USB Charging Port
14. Battery Compartment Cover
15. Snooze/Light Button
16. Hour Button
17. Minute Button

Chapter 2 POWERING ON

1. Install 2pcs 1.5V “AAA” size batteries to the proper terminals in the battery compartment to memorize the time setting and the alarm will ring in case of power outage. NOTE: Batteries are not included and don't support time display or any other functions
2. Connect the adapter line to DC jack , then plug into a 100~240V AC wall power outlet.



Chapter 3 TIME SETTING

1. Press  button once, display  starts flashing.
2. Press  button to set the hour, press button to set the minute.
3. Press  button to save time or wait for another 5 seconds to confirm automatically.






To change 12H/24H time format Slide switch 12H 24H button to change 12H/24H time format.

Chapter 4 ALARM SETTING

1. Make sure the slide switch button towards the left "ON".


2. Press  button, the alarm indicator  will light up, the  display starts flickering.

3. Press  button to set the hour, press  button to set the minute.




4. Press  button to save time or just wait for another 5 seconds to confirm automatically.


5. Slide switch button  to adjust alarm volume.

Chapter 5 DIMMER

1. Slide switch button  to adjust the brightness of display to your preference.


Chapter 6 NIGHT LIGHT



1. Turn on NIGHT LIGHT Press  button then the night light will turn on.
2. Turn off NIGHT LIGHT Long press button for 2 seconds or press  it repeatedly until the night light turns off.
3. Switch NIGHT LIGHT Color When the night light turns on, you can press  button to switch to the color as you desired. The night light colors are as below:



Turn off Alarm

When alarm goes off:

1. Press  button to temporarily turn off alarm for 9 minutes. Alarm will ring every next 9 minutes.

2. Press  button to turn off alarm for 24 hours. The alarm indicator  is still on, which means alarm is still activated and will ring after 24 hours.



ALM

3. To cancel alarm, slide switch button to ON •• OFF, alarm indicator will disappear from the display.

Chapter 7 DST SWITCH



DST

1. Hold press to light up the indicator . An hour will be added to the current time on the display.



DST

2. To turn off DST, hold press until the Indicator turns off.

Chapter 8 USB CHARGING

Plug charging cable into device such as phone or tablet. Device can charge both your phone or tablet at the same time. The maximum charge current is 1 Ampere.

Chapter 9 WARRANTY


1. Mesqool E-commerce Co., Ltd warrants the Mesqool branded alarm clock and accessories contained in the original packaging against defects in materials and workmanship when used normally in accordance with Mesqool's published guidelines for a period of 1 year and replacement service within 3 months from the date of original retail purchase by the end-user purchaser("Warranty Period"). Moreover, 1-month refund policy is available for the original consumer or recipient.
2. The original consumer or recipient can sign up on our website for a 18 months extended warranty.
3. If you need any help for this product, please feel free to contact us by Email: support-us@mesqool.com

Remarks:

- a. This warranty does not include: damage to product or components resulting from abuse, accident, or climatic/environmental conditions; damage resulting from normal wear or tear, misuse, or unauthorized repair; changes in surface finishes due to aging or exposure to light. The company's obligation under this warranty shall be limited to repairing the product or component, or at its option, replacing it with a new product or components.
- b. Our company reserves the right to revise the warranty polices without notification. Please check our website to obtain the latest updates.

Made in China





[Mesqool CR1008 Digital LED Alarm Clock](#) [pdf] Instruction Manual
CR1008, CR1008 Digital LED Alarm Clock, Digital LED Alarm Clock, LED Alarm Clock, Alarm Clock, Clock

References

- [User Manual](#)