

Metaframe PF100 Digital Photo Frame User Guide

Home » Metaframe » Metaframe PF100 Digital Photo Frame User Guide 🖺

Contents

- 1 Metaframe PF100 Digital Photo
- Frame
- **2 Product Quick Start**
- 3 Quick Start
- 4 Common problems
- **5 FCC STATEMENT**
- 6 Documents / Resources
 - **6.1 References**



Metaframe PF100 Digital Photo Frame



Product Information

The Cloud Photo Frame, also known as Metaframe, is a digital photo frame that allows you to display and share your photos and videos wirelessly. It comes with a user-friendly mobile app that enables easy management and control of the frame.

Product Quick Start

- 1. **Photo frame activation:** To set up the photo frame for the first time, follow these steps:
 - Secure the frame for support and connect it to a power supply (the frame will turn on automatically).
 - Follow the activation wizard to select the language of the photo frame.
 - Connect the photo frame to the Internet via the wireless network settings.
 - If a new version of the Metaframe software is available, it is recommended to complete the software upgrade immediately.
 - After completing the wizard, you will receive the FrameID and Frame Email for the frame.

2. Register an account and add a photo frame:

- Download the Metaframe app from Google Play or App Store and sign up for a new account using your email address.
- Login with your new account and click on "Add Photo Frame" as prompted.
- In the "Add Frame" window, fill in the FrameID and name for the frame.
- Click "Send" to share selected photos to the photo frame. You can also preview and filter the photos before sending.

3. Share photos to frames via Email:

- Each frame has a unique Frame Email. You can send photos to this email address for the frame to receive them.
- There is no limit to the number of photos you can share via email, but the maximum size is 30MB. Videos cannot be shared to the photo frame.

4. Invite friends to share photos:

- You can share the photo frame with your family and friends in various ways:
 - Send the FrameID to a friend.
 - Send Frame Email to a friend.
 - Click "Invite Friends" in the Metaframe app and enter your friend's email address to send an invitation.
 - Click "Invite Friends" in the Metaframe app and send the invitation link to your friends via social media programs.
- 5. **Special Note:** Recommended wireless network connection for photo frames:
 - To access all the features of Metaframe, it is recommended to connect your photo frame to a wireless network.

Share a Photo

To share a photo from the Metaframe app:

- 1. Open the Metaframe app and go to the "Gallery" tab.
- 2. Select the images or videos you want to share.
- 3. You can swipe left or right to batch select images.

Please read this instruction throughly before using this product and keep it for future reference.

Quick Start

Photo frame activation

If you are using Metaframe for the first time, please follow the steps below to complete the photo frame setup:

- First, secure the frame for support and connect it to the power supply (the frame will turn on automatically);
- After the photo frame is powered on, it will go to the activation wizard;
- Follow the wizard to select the language of the photo frame;
- Connect the photo frame to the Internet via the wireless network settings;
- If a new version of the Metaframe software is available, you will be prompted with a message box. If prompted It is recommended that you complete the software upgrade immediately.
- After completing the wizard, you will get the frame FrameID and Frame Email.

Register an account and add a photo frame

• Download the "Metaframe" app.

- Search for "Metaframe" in "Google Play" or "APP Store" and download it. Download.
- Sign up for a new account using your email address.
- After registering, use your new account to login. You will enter the main interface of APP, please click "Add Photo Frame" button as prompted. button.
- In the "Add Frame" window, fill in the frame FrameID and name the frame.



• Once you're done adding photos, you can share them in the frame!

Note: The first user to add a frame is the owner user by default, and all users who add frames after that are guest users. Guest After a guest user adds a photo frame, the owner of the photo frame will receive a prompt message on Metaframe APP and the photo frame, and the owner can choose to agree or reject the message on Metaframe APP or the photo frame. The owner of the photo frame will receive a prompt message on Metaframe APP and the photo frame, and the owner of the photo frame can choose to agree or reject on Metaframe APP or the photo frame, and after agreeing, the guest user can share photos to the photo frame.


1. Share a photo

Sharing photos to frames via Metaframe APP

• Go to the Metaframe APP and click on the "Gallery" tab below.



- Select the images and videos you want to share, and you can also swipe left and right to batch select images.
- After clicking "Next", you can choose which frame you want to share these pictures to, and you can choose to share them to more than one frame at the same time. You can choose to share them in more than one frame at the same time.



• Click "Send" to share these photos to the photo frame; you can also click "Send Preview" to view the photos you selected, in the preview screen you can filter these photos again. You can also click "Send Preview" to see

the photos you have selected, and in the preview screen, you can filter these photos again.

Warning

- You can select up to 100 pictures and videos per send. The maximum length of the video you can send through the APP is 15s, when you select more than 15s, only the first 15s of the video will be sent by default.
- When you select a video longer than 15s, only the first 15s of the video will be sent by default, you can also crop the video by long-pressing the video to enter the preview interface.
- You can also crop the video after long press the video to enter the preview interface, and then send any continuous clip within 15s in the video.

Share photos to frames via Email

- Each frame has a unique Frame Email.
- After sending photos to this email address, the frame can receive them as well.

There is no limit to the number of photos you can share via email, only the size, maximum 30M. you can't share Video to photo frame.

Invite friends to share photos

- You can share the photo frame with your family and friends in many ways, so that everyone can share the
 wonderful images to the photo frame together.
- · The ways include:
 - Send the FrameID to a friend.
 - Send Frame Email to a friend.
 - Click the "Invite Friends" button in the Metaframe APP and enter your friend's e-mail address to send the invitation
 - Click the "Invite Friends" button in the Metaframe APP and send the invitation link to your friends via social media programs.

Special Note: Recommended wireless network connection for photo frames

 Metaframe More Great Features requires an internet connection and it is recommended that you connect your device to a wireless network immediately.

Common problems

Picture frame end

How do I make a photo frame play a specified photo?

- After entering the album, click the "√" button in the upper right corner or long press any photo to enter the photo selection mode, then select the photo you want to play and click the play button in the top operation menu.
- Select the photo you want to play and click the play button in the top menu.

Support for sending pictures via e-mail?

- · Support.
- Click: Settings=>Friends to view the Frame Email of your frame, and use the e-mail address* to send to Frame
 Email.

Is there a limit to sending pictures via email? Is it possible to send videos via email?

- There is no limit to the number of photos you can send via email, only the size, which is currently no more than 30 megabytes.
- It is not possible to send videos by e-mail.

Can I delete photos in bulk?

- · You can batch delete.
- Click Albums in order => Batch (top right corner) => Select All or Manually Select Photos => Delete.

Does it support connecting to hidden WiFi?

- · Support to add.
- Click Settings => WiFi => Add Network (bottom) => Fill out the form => Submit.

What should I do if I can't load FrameID?

- As a priority, check if your frame is connected to the Internet via WiFi, or if it is, try disconnecting it and restarting it.
- If not, go to Settings/About and check if the first 3 items are all checked.
- If it is not solved, go to Settings/About and check if the first 3 items are correct, if yes, try to restart the frame.
- If you still can't get the Frameld after restarting, you need to send the popup box that appears on the frame to the after-sales service.
- If the first 3 items are not correct, please move the frame to a place closer to the router and try again.

Why does the picture frame automatically turn off the screen every five minutes?

When the human body sensor is turned on, the frame will automatically enter sleep mode when there is no person moving in front of the frame for more than 5 minutes to minimize the disturbance and extend the life of the frame. disturbances and extend the life of the frame.

APP Client

How do I make a photo frame play a specified photo?

 Send up to 100 at a time, either as a combination of photos and videos, or send 100 photos or 100 videos individually.

APP Can photos and videos be sent together?

· You can.

What is the maximum number of photo frames an APP user can be tied to?

• A user can bind up to 20 frames.

How long videos are supported to be sent?

- It supports sending short videos within 15s, and sends the first 15s of the video by default when the video over 15s is selected, and it also supports intercepting any clip of 15s in APP.
- It also supports to intercept any clip of 15s in the APP.

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection againstharmful interference in a residential installation. This equipment generates, uses and can radiateradio frequency energy and, if not installed and used in accordance with the instructions, maycause harmful interference to radio communications. However, there is no guarantee thatinterference will not occur in a particular installation. If this equipment does cause harmfulinterference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of thefollowing measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. This device may not cause harmful interference
- 2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

Documents / Resources

Metaframe PF100 Digital Photo Frame [pdf] User Guide PF100, 2ALIJ-PF100, 2ALIJPF100, PF100 Digital Photo Frame, Digital Photo Frame, Photo Frame, Frame

References

Manuals+,