



METALLIC GEAR Neo V2 Series Mini-ITX Case User Guide

[Home](#) » [METALLIC GEAR](#) » METALLIC GEAR Neo V2 Series Mini-ITX Case User Guide 



Neo V2 Series
Quick Guide

Contents

- [1 Heating On / Temperature Control](#)
- [2 Heating Off/ Frost Protection](#)
- [3 Setting The Clock](#)
- [4 Editing Comfort Levels](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)

Heating On / Temperature Control

To make a temporary change to the temperature setting press the V or ^ key, set your desired temperature, and press ✓

If the set temperature is above the room temperature the " symbol will be displayed, indicating the heating is now on.

This set temperature will be maintained until the next comfort level.

Heating Off/ Frost Protection

To enable frost protection, use the < > keys to select C) then press the ✓ key once. The  symbol will be displayed.

In this mode, the heating will be turned off, but if the temperature falls below your frost protection temperature, the heating will then turn on.

To return to your heating schedule, disable frost protection by using the < > keys to select C) then press ✓, the  symbol will disappear.



Heating on



Frost Protection On

Setting The Clock

Use the < > keys to select C) then press and hold the ✓ key. Use the > key to select CLOCK, and press the ✓ key.

Use the v ^ keys to set the year, and press ✓

Repeat the steps to set the month, day, hours & minutes.

Use the V key to select C), and press the ✓ key to turn the display on.

Note: The clock will automatically be set when paired to the neoHub.

Editing Comfort Levels

Use the < > keys to select EDIT, and press the ✓ key once.

Use the < > keys to select the days to edit, press ✓

WAKE will now flash, press the ✓ key to edit the WAKE level. Use the V ^ keys to adjust the hours, press ✓

Use the V ^ keys to adjust the minutes, and press ✓

Use the v ^ keys to adjust the temperature, press ✓

Use the < > keys to select LEAVE, press ✓

Repeat the steps above for the Leave, Return & Sleep settings.

For any levels that you don't want to use, adjust the time to—: To confirm changes and exit, use < > to select DONE, press ✓

Documents / Resources



[METALLIC GEAR Neo V2 Series Mini-ITX Case](#) [pdf] User Guide
Neo V2 Series Mini-ITX Case, Neo V2 Series, Mini-ITX Case, Case