

# MettaX MC202A Integrated Video Monitoring User Manual

## Contents

- [1 Introduction](#)
- [2 System Overview](#)
- [3 Installation Preparation](#)
- [4 Preparation for Installation Materials and Tools](#)
- [5 Installation](#)
- [6 Device configuration](#)
- [7 Acceptance and Cleaning](#)
- [8 Documents / Resources](#)
  - [8.1 References](#)
- [9 Related Posts](#)

## Introduction

To guide engineers in the correct and efficient installation of MC202A and its accessories, and to improve installation efficiency, this MC202A Solution Installation Guide has been prepared. This document primarily includes: Preamble, System Overview, Installation Preparation, Installation Introduction, Acceptance, and Cleaning. This document is intended for installation engineers. We reserve the right to interpret this document and modify the information and descriptions contained herein. In the event of any changes to the content of this manual, no separate notification will be provided.

## Important Notice

1. Prior to installation, park the vehicle on level ground and turn off the engine (do not park the vehicle on slopes or inclined roads).
2. Please carefully read the section on the packing list and thoroughly inspect it upon unpacking.
3. Please carefully read the section on tool list and ensure the availability of installation tools before proceeding with the installation.
4. Prior to installation, observe the vehicle's surroundings and adhere to the following principles:
  - The installation position and wiring of the product should not obstruct the driver's visibility or adjustment of the rear-view mirror and sun visor.
  - The lens for monitoring the road conditions ahead of the vehicle must be within the working range of the windscreen wipers.
  - The installation position of the in-cabin driver monitoring camera should comply with local regulations.
  - The installation position should facilitate the replacement and maintenance of the Micro SD card and standard SIM card.
5. Choose a suitable installation position based on the vehicle's environment. This document serves as a

reference only.

6. Select the appropriate power connection method based on the vehicle's environmental conditions. Power connection should be performed by professionals, as improper operation of the vehicle's power system by non-professionals may be dangerous. This document serves as a reference only.
7. If any issues arise during the installation of special vehicles, please contact the product supplier promptly for support.
8. During installation, the Mxtool application is required for debugging and configuring the MC202A.
9. Scan the QR code below or search for and download the MXTool application from the application store. Once downloaded, you can connect the application to the MC202A to configure the device's operational parameters.

## **System Overview**

### **Product Overview**

MC202A is an smart dash cam with built-in single recording cameras. It helps drivers reduce traffic accidents and assists fleet management in improving efficiency. Based on artificial intelligence technology, it can proactively detect dangerous driving events and unsafe driving behaviors. It supports sending local real-time alerts to the driver to avoid risks and uploads the events to the fleet management platform for driver training. It transmits real-time and accurate vehicle location information and operational data to the fleet management platform. It provides high-quality remote intercom and real-time video playback, making fleet management easier and more efficient. This product is suitable for various weather conditions such as day and night, sunny, and rainy. It can be installed in vehicles such as buses, taxis, passenger cars, trucks, hazardous goods transport vehicles, school buses, dump trucks, and sanitation vehicles.

### **Schematic diagram powered by standard power cable:**

Schematic diagram powered by standard power cable:

## **Installation Preparation**

### **Installation Technical Requirements**

Installation engineers should be familiar with the product's features, applications, and overall composition. Installation engineers should know vehicle circuits, structures, and commonly used installation methods for in-vehicle devices.

### **Understanding the Installation Environment**

Before equipment installation, relevant personnel should have a clear understanding of the vehicle model, installation position of the device, cable types and lengths required for different vehicle models, and the list of commonly used auxiliary materials. This ensures the smooth completion of equipment installation and debugging.

### **Vehicle Condition and Related Electrical Information**

Confirmation of vehicle information is the basic prerequisite for successful installation and the assurance of role allocation to avoid vehicle damage. For each component, the next step can only proceed after clear confirmation, with confirmation by the vehicle responsible person and the installation personnel for each operation.

1. Check for any damage to the vehicle's exterior and interior components.
2. Check if the vehicle can be started normally.
3. Check the status of the vehicle's power supply system.

**Note:** Confirming the above information is crucial. Installation can only proceed after confirmation of normal conditions.

## Vehicle Power Connection

It requires the operation of professional installers. The following mainly describes the method of connecting the vehicle's power supply according to the product's power cable requirements.

1. Tools required: multi-meter.
2. Selection of Power Connection Location When the vehicle is parked and the ignition is OFF, use a multimeter to check if the circuit is powered. If it is positive, it is determined to be a constant power supply, and then measure the voltage. When the vehicle is parked but the ACC is ON or ignited position, use a multimeter to check if the circuit is powered. If it is negative when ACC is OFF and positive when ACC is ON, it is determined to be the ACC cable, and then measure the voltage.
3. Voltage Measurement at Power Connection Point Constant Power Supply: With the vehicle is parked and the ignition is OFF, use a multi-meter to measure the voltage of the constant power supply cable, which is approximately 24 V or 12 V. If multiple cables have voltages within this range, select the cable with higher current as the constant power supply connection cable.  
ACC: When the vehicle ACC is in the ON position or ignited state, use a multimeter to measure if the voltage is 24 V or 12 V. If it is 0 in the OFF state and 24 V or 12 V in the ACC ON position or ignited state, select the cable as the ACC power supply connection cable.

**Note:** When connecting the power supply, measure the positive and negative terminals of the power supply first with a multi-meter to avoid errors.

## Preparation for Installation Materials and Tools

### Package Inventory Check

After unpacking the product, please ensure the device is intact and all accessories are included.

### Installation Materials and Tools

#### Preparing standard SIM Card and Micro SD Memory Card

To ensure proper online communication and data storage of the device, please prepare a compatible Micro standard SIM card and a Micro SD memory card that meets the quality requirements before installation.

## Installation

### Installing standard SIM Card and Memory Card

Installing the standard SIM card and Micro SD card as shown in the following diagram (pay attention to the insertion direction of these cards). During installation, make sure it feels smooth and flexible. When pushing the card, you should hear a clear "click" sound, indicating that the card is correctly inserted. If you feel significant friction or resistance during installation, it means the card is inserted in the wrong direction. In such cases, promptly remove the card to avoid damaging it. If the Micro SD card and standard SIM card are too small to be inserted into the slot manually, you can place the card into the slot and then use the included pry tool to push it in.

[Diagram: Insertion of standard SIM card and Micro SD card]

### Note:

1. Due to the operating temperature range of the device from -20°C to +70°C, the Micro SD card and SIM card should be able to work properly for an extended period in harsh environments. Specifically, the metal contacts on consumer-grade Micro SD cards and SIM cards are prone to oxidation under prolonged exposure to heat,

humidity, or salt spray conditions. Frequent insertion and removal of cards can lead to contact wear, and the card slot can experience deformation or bending under constant pressure, resulting in poor contact. Therefore, if you are using a SIM card, for industrial equipment, industrial plastic or ceramic M2M cards (MP2/MP3/MS1 grade) with a working temperature range of -40°C to 105°C is recommended. If using a Micro SD card, an industrial-grade Micro SD card should be used, which offers strong stability and can be used within a wide temperature range (-40°C to 85°C). For safety purposes, when purchasing the device, it is recommended to use Micro SD cards that have been verified by our company. If you choose to purchase unverified Micro SD cards, there may be a risk of damaging the device, thus affecting its lifespan.

2. Before installing the SIM card, please check the metal contact surface of the SIM card for any dirt (such as dust, fingerprints, or watermarks). If there is any, use a non-woven cloth or rubber to clean the surface.
3. When installing the SIM card, avoid touching the metal surface of the SIM card with your hands to prevent contamination from dust and sweat.

After installing the SIM card and Micro SD card, tighten the card slot panel and the screws. Once the SIM card and Micro SD card are installed, remove the lens protective film from the front and rear lenses of the device.

### **Choice of Installation Area for the Main Unit**

The installation area requirements for MC202A are as follows:

1. The device must be installed in the middle of the windshield. Typically, it is installed in the area above the center line of the windshield, in the vicinity of the rear-view mirror. If it is not possible to install the device in the middle as required, a deviation of less than 5 cm to the left or right is allowed (the deviation of the device relative to the center line of the windshield is calculated using the center line of the front lens).
2. The lens of the road condition monitoring camera must be within the working range of the left and right windshield wipers (ensuring that the screen of the road condition monitoring lens is clean and free from stains).
3. It is recommended to avoid installing other electronic devices, including smart rear-view mirrors, electronic tags, etc., around the device, as it may affect the device's positioning signal. The installation position should ensure that the main unit does not obstruct the driver's view of the front blind spot reflector, and that there are no obstacles (such as the interior rear-view mirror or glass coating) in front of and around the camera lens in the driver's cabin monitoring view.

The general election of the installation area is shown in the diagram below:[Diagram: Installation area for the main unit]

### **Installation of the main unit.**

1. Park the vehicle on a level surface.
2. Clean the inside and outside of the target installation area on the windshield using an alcohol swab. Ensure that no dirt or debris on the glass obstructs the view of the road condition monitoring lens. Make sure the glass is dry.
3. Remove the protective film from the 3M tape of the mounting base and attach it to the windshield
4. Press the device firmly against the windshield for 10 seconds, ensuring that there are no air bubbles between the main unit and the glass.

## Adjustment and Fixation of the device

When fix the camera, ensure that the cabin camera screen meets the following conditions:

- The center of the cabin should be positioned in the middle of the screen.
- The cabin screen should be horizontal.
- The vehicle's steering wheel should be displayed in the lower left/right corner of the screen.

The properly adjusted cabin monitoring camera rendering is shown below:

**Note:** Only when the device is securely connected to the vehicle, can the device be powered on. If the device is fixed after the power connection, it should be powered on again before testing or use.

## Power Connection, Signal Cable, and Cable Connection

Connect the power/ACC/GND to the vehicle's power supply line.

### **Note:**

The power line should preferably be connected using "dedicated non-stripping connectors" (no need for stripping, to avoid the risk of electric leakage) and wrapped with insulating tape to prevent electric leakage/short circuit. If there are no special non-stripping connectors available, stripping wires can also be used for the connection. In this case, the connection process must comply with standard specifications. After the connection is completed, wrap it with insulating tape to avoid electric leakage/short circuit.

## Device configuration

After the device is powered on, adjust it using the mobile app MXTool. Please refer to the MXTool user manual for instructions.

## Acceptance and Cleaning

### **Cleaning**

Clean up the installation site, and collect and remove tools and waste materials. Return any original items to their original positions in the vehicle. The installation work is now complete.

### **Installation Acceptance**

Conduct acceptance based on the acceptance checklist provided by the customer, focusing on the installation details and parameter settings.

1. Pay close attention to the parameter settings and take screenshots for documentation.
2. Verify the video image quality and capture and save sample videos. After the installation is complete, take photographs of all the devices and the central console.
  1. Capture installation position photos of all components.
  2. Take a rendered photo of the cabin after the installation is complete.

## Documents / Resources

|   |  |
|---|--|
|  | <p><a href="#">MettaX MC202A Integrated Video Monitoring</a> [pdf] User Manual<br/>MC202A Integrated Video Monitoring, MC202A, Integrated Video Monitoring, Video Monitoring, Monitoring</p> |
|---|--|

## References

- [User Manual](#)

### Manuals+ Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.