




## MewooFun QS16J Cat Window Perch User Manual

[Home](#) » [MewooFun](#) » MewooFun QS16J Cat Window Perch User Manual 

### MewooFun QS16J Cat Window Perch




## Contents



- [1 Safety Precaution](#)
- [2 Tools Required](#)
- [3 Assembly Instruction](#)
- [4 Documents / Resources](#)
  - [4.1 References](#)
- [5 Related Posts](#)

## Safety Precaution

### Attention:

- For customer service information please contact E-mail: [service@mewoofun.com](mailto:service@mewoofun.com)
- Please read this manual carefully before assembling and use the product in strict accordance with the manual.
- Please assemble it on the floor with high friction such as carpet to avoid floor damage.
- Do not allow children to climb or hang on the panel.
- Intended to be assembled by an adult. Keep away from children.






## Hook Style | 挂钩款




### Tools Required




### Assembly Instruction

#### 1. Regular Plastic Tube




**!** **Note:** Connect two metal tubes to lengthen. Press and hold the bead in the hole. If they are connected in place, the bead will pop out of the hole .




#### Extended Metal Tube


2. **!** **Note:** Align the holes of the metal tubes with those of the brackets.




3. **!** **Note:** Insert P05 into the holes.



4. **!** **Note:** Wrap the metal tube with fabric P01.




5. **!** **Note:** Insert P05 into the holes.




**!** **Note:** Store the pry tool here. Use the pry tool to remove easily.

6. **!** **Note:** Press the button on the bracket. Slide it to be vertical with the window sill.





## Documents / Resources



[MewooFun QS16J Cat Window Perch](#) [pdf] User Manual  
QS16J.000, QS16J Cat Window Perch, QS16J, Cat Window Perch, Window Perch, Perch

## References

- [User Manual](#)

## **Manuals+. Privacy Policy**

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.